



B3404CVA/CVF	0	0	0	0	0	0	0	0	0	0	0	0	0	0
B3604CMA	0	0	0	0	0	0	0	0	0	0	0	0	0	0
B3404CMA	0	0	0	0	0	0	0	0	0	0	0	0	0	0
B3402FEA	0	0	0	0	0	0	0	0	0	0	0	0	0	0
B3402FBA	0	0	0	0	0	0	0	0	0	0	0	0	0	0
B3302CEA/FEA(B53)	0	0	0	0	0	0	0	0	0	0	0	0	0	0
B2502FVA	0	0	0	0	0	0	0	0	0	0	0	0	0	0
B2502FBA	0	0	0	0	0	0	0	0	0	0	0	0	0	0
B2502CVA	0	0	0	0	0	0	0	0	0	0	0	0	0	0
B2502CBA	0	0	0	0	0	0	0	0	0	0	0	0	0	0
B2402FVA	0	0	0	0	0	0	0	0	0	0	0	0	0	0
B2402FBA	0	0	0	0	0	0	0	0	0	0	0	0	0	0
B2402CVA	0	0	0	0	0	0	0	0	0	0	0	0	0	0
B2402CBA	0	0	0	0	0	0	0	0	0	0	0	0	0	0
B1502CVA	0	0	0	0	0	0	0	0	0	0	X <sup>2</sup>	0	0	0
B1502CGA	0	0	0	0	0	0	0	0	0	0	X <sup>2</sup>	0	0	0
B1502CBA	0	0	0	0	0	0	0	0	0	0	X <sup>2</sup>	0	0	0
B1500CEPEY	X <sup>1</sup>	0	0	0	0	0	0	0	0	0	X <sup>2</sup>	0	0	0
B1500CEPE	0	0	0	0	0	0	0	0	0	0	0	0	0	0
B1500CEAEY	X <sup>1</sup>	0	0	0	0	0	0	0	0	0	X <sup>2</sup>	0	0	0
B1500CEAE	0	0	0	0	0	0	0	0	0	0	0	0	0	0
B1500CBA	0	0	0	0	0	0	0	0	0	0	0	0	0	0
B1402CVA	0	0	0	0	0	0	0	0	0	0	X <sup>2</sup>	0	0	0
B1402CGA	0	0	0	0	0	0	0	0	0	0	X <sup>2</sup>	0	0	0
B1402CBA	0	0	0	0	0	0	0	0	0	0	X <sup>2</sup>	0	0	0
B1400CEPEY	X <sup>1</sup>	0	0	0	0	0	0	0	0	0	X <sup>2</sup>	0	0	0
B1400CEPE	0	0	0	0	0	0	0	0	0	0	0	0	0	0
B1400CEAEY	X <sup>1</sup>	0	0	0	0	0	0	0	0	0	X <sup>2</sup>	0	0	0
B1400CEAE	0	0	0	0	0	0	0	0	0	0	0	0	0	0
B1400CBA	0	0	0	0	0	0	0	0	0	0	0	0	0	0

See the ASUS Simpro Dock for more information on our website page.

\* These specific ExpertBooks have higher power requirements, so the Simpro Dock 2 with 120W power delivery, is not recommended. If these docks are used, the notebook needs to be plugged in externally for optimal performance.

1 The dock's power button can be sync with the notebook's power button. Please check notebooks' specification for full details.

2 When connected to non-Thunderbolt or display out systems, Simpro Dock 2 will not retain its Thunderbolt or display out functionality.

This document was last updated on February 26, 2024.