

Electronic ID and SmartCard Reader


User Manual

Product Code: AK-CR-14BK

AKASA Company notices


The information contained in this document is subject to change without notice. All rights reserved. Reproduction, adaptation, or translation of this material is prohibited without prior written permission of AKASA, except as allowed under copyright laws. The only warranties for AKASA products and services are set forth in the express warranty statements accompanying such products and services. Nothing herein should be construed as constituting an additional warranty. AKASA shall not be liable for technical or editorial errors or omissions contained herein.

Contents




GB Smart Card Reader
 FR Lecteur Smart Card
 DE Chipkartenleser
 PT Leitor de Smart Card
 ES Lector de Smart Card
 RU СЧИТЫВАТЕЛЬ СМАРТ-КАРТ
 CZ Čtečka chytrých karet
 PL Odczytywacz kart inteligentnych
 JP スマートカードリーダー
 CN 智能卡读卡器

Installation



GB Connect the USB cable to the USB port on PC or Mac
 FR Connectez le câble USB au port USB sur un PC ou un Mac
 DE Schließen Sie das USB-Kabel an den USB-Anschluss am PC oder Mac an
 PT Conecte o cabo USB na porta USB do PC ou Mac
 ES Conecte el cable USB al puerto USB del PC o Mac
 RU Подсоедините кабель USB к порту USB на ПК или Mac
 CZ Připojte USB kabel k USB portu počítače PC nebo Mac
 PL Podłącz kabel USB do portu USB na komputerze PC lub Mac
 JP USB ケーブルはUSB ポートに接続する
 CN 将USB线材接上PC或Mac的USB端口



GB Insert the Smart Card (with chip on the top) into the card reader port
 FR Insérez la carte Smart Card (avec la puce vers le haut) dans le port du lecteur de carte
 DE Legen Sie die Smart Card (mit Chip oben) in den Kartenleser-Port
 PT Insira o Smart Card (com o chip para cima) no slot do leitor
 ES Inserte la Smart Card (con el chip en la parte superior) en el puerto lector de tarjetas
 RU Вставьте смарт-карту (чипом вверх) в порт картридера.
 CZ Vložte do PLportu čtečky karet chytrou kartu (čipem nahoru)
 PL Włóż kartę inteligentną (z czipem na górze) do portu odczytywacza kart
 JP スマートカードをスマートカードリーダーに挿入します。(チップが上になる)
 CN 将智能卡插入智能卡读卡器(有芯片的那面在上)

Operation

GB Win7 / Win8.X / 10 /11, Linux, macOS have the driver already pre-installed so no action is required.
 FR Le pilote est déjà préinstallé dans Win7 / Win8.X / 10 /11, Linux, macOS, donc aucune action n'est requise.
 DE Win7 / Win8.X / 10 /11, Linux, macOS haben die Treiberprogramme bereits vorinstalliert, so dass keine Maßnahmen erforderlich sind.
 PT Win7 / Win8.X / 10 /11, Linux, macOS já possuem o driver pré-instalado, por isso não requer drivers.
 ES Win7 / Win8.X / 10 /11, Linux, macOS ya tienen el controlador preinstalado y no necesita hacer nada.
 RU В ОС Win7 / Win8.X / 10 /11, Linux, macOS имеется предустановленный драйвер, поэтому никаких действий не требуется.
 CZ Win7 / Win8.X / 10 /11, Linux, macOS již mají ovladač předem nainstalovaný, žádná akce proto není zapotřebí.
 PL Systemy Win7 / Win8.X / 10 /11, Linux, macOS mają sterownik już zainstalowany, więc nie wymaga to żadnych dodatkowych działań.
 JP Win7 / Win8.X / 10 /11, Linux, macOS ドライバ不要。Windows標準のドライバで動作します。
 CN Win7 / Win8.X / 10 /11, Linux, macOS 系统已内置驱动程序·不需特别安装即可使用。