

# SCANPAL™ EDA52/ EDA52 HC/ EDA56 WI-FI 6/ EDA57 MOBILE COMPUTER

---

Accessories Guide (6PIN)

---



Honeywell

# TABLE OF CONTENTS

## 3 CHARGERS

BASIC CHARGERS

BATTERY CHARGERS

NON-BOOTED UNIVERSAL DOCKS

## 4 MOBILE

MOBILE ACCESSORIES

## 5 POWER SUPPLY

BATTERY

POWER ADAPTER AND PLUGS

# CHARGERS

## Basic Chargers



EDA50-HB-R



EDA52-HB-0  
EDA52-HB-1  
EDA52-HB-2  
EDA52-HB-3  
EDA52-HB-5



EDA52-CB-0  
EDA52-CB-1  
EDA52-CB-2  
EDA52-CB-3  
EDA52-CB-5

### Single Charging Dock

Charging dock for ScanPal™ EDA50/EDA50HC/EDA51, EDA52/EDA52HC, EDA56 Wi-Fi 6, EDA57.

For EDA52/EDA52HC, EDA56 Wi-Fi 6, EDA57 charging needs to be worked with EDA52-ADC. Compatible with EDA51/EDA52 scan handle.

Does not include charging cable; cable (CBL-500-120-S00) and power adapter and plugs (50130570-001) must be ordered separately.

### Single Charging Home Base

Single charging home base for ScanPal EDA52/EDA52 HC/EDA56 Wi-Fi 6/EDA57 terminal and battery. Kit contains power supply and power cord. (-0 no power cord, -1 for U.S., -2 for Europe, -3 for UK, and -5 for AU). Compatible with EDA52 scan handle.

### Quad Bay Charging Base

Quad bay charging base for ScanPal EDA52/EDA52HC/EDA56 Wi-Fi 6/EDA57 terminals and batteries. Kit contains power supply and power cord. (-0 no power cord, -1 for U.S., -2 for Europe, -3 for UK, and -5 for AU). Compatible with EDA52 scan handle.

## Non-Booted Universal Docks (for 6-pin models only)



EDA52-NB-UVN-0  
EDA52-NB-UVN-2



EDA52-EB-UVN-0  
EDA52-EB-UVN-2



EDA52-DB-UVN-0  
EDA52-DB-UVN-2

### Non-booted Net Base

EDA52/EDA52 HC/EDA56 Wi-Fi 6/EDA57 non-booted net base for Ethernet communications and recharging up to four computers. Kit includes net base and power cord (-0 no power cord, -2 for Europe).

### Non-booted Ethernet Base

EDA52/EDA52 HC/EDA56 Wi-Fi 6/EDA57 Non-booted Ethernet base for recharging one computer and one battery, Ethernet communications. Kit includes Ethernet home base and power cord (-0 no power cord, -2 for Europe)

### Non-booted Display Dock

EDA52/EDA52 HC/EDA56 Wi-Fi 6/EDA57 non-booted display dock for recharging one computer, connection with an external display, extending I/O for HDMI, Ethernet communications. Kit includes display base and power cord (-0 no power cord, -2 for Europe).

## Battery Chargers



EDA52-QBC-0  
EDA52-QBC-1  
EDA52-QBC-2  
EDA52-QBC-3  
EDA52-QBC-5

### Quad Battery Charger

Quad battery charger for ScanPal EDA52/52HC/EDA56 Wi-Fi 6/EDA57 batteries. Kit contains power supply and power cord. (-0 no power cord, -1 for U.S., -2 for Europe, -3 for UK, and -5 for AU).

# MOBILE

## Mobile Accessories



EDA52-WS-10PK

### Wrist Strap

Wrist strap for ScanPal EDA52/EDA52 HC/EDA56 Wi-Fi 6/EDA57 (10pcs/kit).



EDA52-HS-10PK

### Hand Strap

Hand strap for ScanPal EDA52/EDA52 HC/EDA56 Wi-Fi 6 (10pcs/kit).



3012-0760-001

### Hand Strap

Hand strap for ScanPal EDA57 (1pcs/kit).



EDA52-SP-10PK

### Screen Film

Screen film for ScanPal EDA52/EDA52 HC/EDA56 Wi-Fi 6/EDA57 (10pcs/kit).



EDA52-RB-0

### Rubber Boot

Rubber boot for ScanPal EDA52/EDA52 HC/EDA56 Wi-Fi 6/EDA57.



EDA52-SH-R

### Scan Handle

Scan handle for ScanPal EDA52/EDA52 HC/EDA56 Wi-Fi 6/EDA57. Compatible with EDA52/EDA57 hand strap.



EDA52-ADC

### Backwards Adapter Cup

EDA52/EDA52 HC/EDA56 Wi-Fi 6/EDA57 backwards adapter to work with EDA50-HB-R accessories.



EDA52-SN-USB-0

### USB Cup (6-pin models only)

EDA52/EDA52 HC/EDA56 Wi-Fi 6/EDA57 snap-on USB cup for standard USB port.



EDA52-UCP-N

### Universal Cup (6-pin models only)

EDA52/EDA52 HC/EDA56 Wi-Fi 6/EDA57 Universal Cup to be worked with CT40 series universal docks.



IH25-BR-5

### RFID Brackets

IH25 bracket for ScanPal EDA52/EDA52 HC/EDA56 Wi-Fi 6/EDA57. Terminal without rubber boot.



MBL-HDST-USBC

### Mobility USBC Headset

Mobility headset with PTT, USB-C interface for CT30XP/EDA52/EDA52 HC/EDA56 Wi-Fi 6/EDA57.

# POWER SUPPLY

## Battery



50172021-001

### Standard Battery Pack

Standard battery pack for ScanPal EDA52/ EDA52 HC/EDA56 Wi-Fi 6/EDA57 (Li-ion, 3.8 V, 4500 mAh) (included with each terminal).



50183310-001

### US Battery Pack

Battery pack for ScanPal EDA52 US (Li-ion, 3.8 V, 4500 mAh) (included in EDA52 US kit).

## Power Adapter and Plugs



50136024-001

### Power Adapter and Plugs

KIT, 5V/2A Power supply, Scanpal EDA50K/ EDA51/EDA52/EDA52 HC/EDA56 Wi-Fi 6/ EDA57/EDA60/EDA61K/EDA70/EDA71. Mobility Edge CT40 / CT60. Includes 5 PLUGS PACKED US, UK, AU, EU, IN adapters.

**For more information**

[sps.honeywell.com](https://sps.honeywell.com)

**Honeywell Safety and  
Productivity Solutions**

855 S Mint St  
Charlotte, NC 28202  
800-582-4263  
[www.honeywell.com](https://www.honeywell.com)

EDA52/EDA52 HC/EDA56 Wi-Fi 6/EDA (6PIN)  
Accessories Guide LTR | Rev D | 12/22  
© 2022 Honeywell International Inc.

**Honeywell**