


Dell G15 5530

Owner's Manual

Notes, cautions, and warnings

 **NOTE:** A NOTE indicates important information that helps you make better use of your product.

 **CAUTION:** A CAUTION indicates either potential damage to hardware or loss of data and tells you how to avoid the problem.

 **WARNING:** A WARNING indicates a potential for property damage, personal injury, or death.

| | |
|---|-----------|
| Chapter 1: Views of Dell G15 5530 | 7 |
| Right | 7 |
| Left | 7 |
| Top | 8 |
| Front | 9 |
| Bottom | 10 |
| Back | 10 |
| Service Tag | 11 |
| Chapter 2: Set up your Dell G15 5530 | 12 |
| Chapter 3: Specifications of Dell G15 5530 | 14 |
| Dimensions and weight | 14 |
| Processor | 14 |
| Chipset | 15 |
| Operating system | 16 |
| Memory | 16 |
| External ports and slots | 16 |
| Internal slots | 17 |
| Ethernet | 17 |
| Wireless module | 17 |
| Audio | 18 |
| Storage | 18 |
| Keyboard | 19 |
| Keyboard shortcuts | 19 |
| Camera | 21 |
| Touchpad | 22 |
| Power adapter | 22 |
| Battery | 23 |
| Display | 24 |
| GPU—Integrated | 25 |
| GPU—Discrete | 25 |
| Operating and storage environment | 26 |
| ComfortView Plus | 26 |
| Chapter 4: Working inside your computer | 27 |
| Safety instructions | 27 |
| Before working inside your computer | 27 |
| Safety precautions | 28 |
| Electrostatic discharge—ESD protection | 28 |
| ESD Field Service kit | 29 |
| Transporting sensitive components | 30 |
| After working inside your computer | 30 |
| BitLocker | 30 |


| | |
|--|-----------|
| Recommended tools..... | 30 |
| Screw list..... | 30 |
| Major components of Dell G15 5530..... | 32 |
| Chapter 5: Removing and installing Customer Replaceable Units (CRUs)..... | 35 |
| Base cover..... | 35 |
| Removing the base cover..... | 35 |
| Installing the base cover..... | 38 |
| Solid-state drive..... | 40 |
| Removing the solid-state drive | 40 |
| Installing the solid-state drive..... | 41 |
| Wireless card..... | 43 |
| Removing the wireless card..... | 43 |
| Installing the wireless card..... | 44 |
| Memory..... | 45 |
| Removing the memory module..... | 45 |
| Installing the memory module..... | 46 |
| Speakers..... | 47 |
| Removing the speakers..... | 47 |
| Installing the speakers..... | 47 |
| Rear cover..... | 48 |
| Removing the rear cover..... | 48 |
| Installing the rear cover..... | 49 |
| Chapter 6: Removing and installing Field Replaceable Units (FRUs)..... | 51 |
| Battery..... | 51 |
| Rechargeable Li-ion battery precautions..... | 51 |
| Removing the battery..... | 51 |
| Installing the battery..... | 53 |
| Touchpad..... | 54 |
| Removing the touchpad..... | 54 |
| Installing the touchpad..... | 55 |
| Display assembly..... | 56 |
| Removing the display assembly..... | 56 |
| Installing the display assembly..... | 59 |
| Keyboard-controller board..... | 61 |
| Removing the keyboard-controller board..... | 61 |
| Installing the keyboard-controller board..... | 62 |
| Power-adapter port..... | 63 |
| Removing the power-adapter port..... | 63 |
| Installing the power-adapter port..... | 64 |
| System board..... | 65 |
| Removing the system board (single-color keyboard)..... | 65 |
| Installing the system board (single-color keyboard)..... | 68 |
| Removing the system board (four-zone keyboard)..... | 71 |
| Installing the system board (four-zone keyboard)..... | 74 |
| USB board..... | 77 |
| Removing the USB board..... | 77 |
| Installing the USB board..... | 78 |

| | |
|--|------------|
| Ethernet and audio board..... | 79 |
| Removing the Ethernet and audio board..... | 79 |
| Installing the Ethernet and audio board..... | 80 |
| Fan and heat-sink assembly..... | 81 |
| Removing the fan and heat-sink assembly | 81 |
| Installing the fan and heat-sink assembly | 82 |
| Power-button assembly..... | 83 |
| Removing the power button..... | 83 |
| Installing the power button..... | 84 |
| Palm-rest and keyboard assembly..... | 85 |
| Removing the palm-rest and keyboard assembly..... | 85 |
| Installing the palm-rest and keyboard assembly..... | 86 |
| Chapter 7: Software..... | 88 |
| Operating system..... | 88 |
| Drivers and downloads..... | 88 |
| Chapter 8: BIOS Setup..... | 89 |
| Entering BIOS Setup program..... | 89 |
| Navigation keys..... | 89 |
| F12 One Time Boot menu..... | 89 |
| System setup options..... | 90 |
| Updating the BIOS..... | 99 |
| Updating the BIOS in Windows..... | 99 |
| Updating the BIOS using the USB drive in Windows..... | 99 |
| Updating the BIOS in Linux and Ubuntu..... | 100 |
| Updating the BIOS from the One-Time boot menu..... | 100 |
| System and setup password..... | 101 |
| Assigning a System Setup password..... | 101 |
| Deleting or changing an existing system password or setup password..... | 101 |
| Clearing CMOS settings..... | 102 |
| Clearing system and setup passwords..... | 102 |
| Chapter 9: Troubleshooting..... | 103 |
| Handling swollen rechargeable Li-ion batteries..... | 103 |
| Locating the Service Tag or Express Service Code of your Dell computer | 103 |
| Dell SupportAssist Pre-boot System Performance Check diagnostics..... | 104 |
| Running the SupportAssist Pre-Boot System Performance Check..... | 104 |
| Built-in self-test (BIST)..... | 104 |
| (Motherboard Built-In Self-Test) M-BIST..... | 104 |
| Logical Built-in Self-test (L-BIST)..... | 105 |
| LCD Built-in Self-Test (LCD-BIST)..... | 105 |
| System-diagnostic lights..... | 106 |
| Recovering the operating system..... | 107 |
| Real-Time Clock (RTC Reset)..... | 107 |
| Backup media and recovery options..... | 107 |
| Network power cycle..... | 107 |
| Drain flea power (perform hard reset)..... | 108 |

Chapter 10: Getting help and contacting Dell..... 109

Views of Dell G15 5530


Right



1. USB 3.2 Gen 1 ports (2)

Connect devices such as external storage devices and printers. Provides data transfer speeds up to 5 Gbps.

Left



1. Network port

Connect an Ethernet (RJ45) cable from a router or a broadband modem for network or Internet access.

2. Universal audio jack

Connect audio-output devices such as speakers, amplifiers, and so on.

3. Battery-status light

Indicates the battery-charge status.

Solid amber—Battery charge is low.

Blinking amber—Battery charge is critical.

Off—Battery is fully charged.

Top



1. Touchpad

Move your finger on the touchpad to move the mouse pointer. Tap to left-click and two fingers tap to right-click.

2. Left-click area

Press to left-click.

3. Right-click area

Press to right-click.

4. Power button

Press to turn on the computer if it is turned off, in sleep state, or in hibernate state.

When the computer is turned on, press the power button to put the computer into sleep state; press and hold the power button for 10 seconds to force shut-down the computer.

NOTE: You can customize the power-button behavior in Windows.


NOTE: The power button does not light up due to its non-backlit design.

Front



- 1. Camera**
Make video calls, capture photos, or record videos.
- 2. Camera-status light**
Turns on when the camera is in use.
- 3. Microphone**
Provides digital sound input for audio recording, voice calls, and so on.

Bottom



1. Left speaker

Provides audio output.


2. Service Tag label

The Service Tag is a unique alphanumeric identifier that enables Dell service technicians to identify the hardware components in your computer and access warranty information.

3. Right speaker

Provides audio output.

Back



1. USB 3.2 Gen 2 (Type-C) port with DisplayPort

Connect devices such as external storage devices, printers, and external displays. Provides data transfer rate of up to 10 Gbps.

Supports DisplayPort 1.4 and also enables you to connect an external display using a display adapter.

NOTE: This port is only available on computers shipped with an NVIDIA GeForce RTX 3050/4050/4060 graphics card.

i **NOTE:** A USB Type-C to DisplayPort adapter (sold separately) is required to connect a DisplayPort device.

2. HDMI port

Connect to a TV, external display or another HDMI-in enabled device. Supports video and audio output.

3. USB 3.2 Gen 1 port


Connect devices such as external storage devices and printers. Provides data transfer speeds up to 5 Gbps.

4. Power-adapter port

Connect the power adapter to charge your computer battery.

Service Tag

The service tag is a unique alphanumeric identifier that allows Dell service technicians to identify the hardware components in your computer and access warranty information.



Set up your Dell G15 5530

About this task

NOTE: The images in this document may differ from your computer depending on the configuration you ordered.

Steps

1. Connect the power adapter and press the power button.



NOTE: The battery may go into power-saving mode during shipment to conserve charge on the battery. Ensure that the power adapter is connected to your computer when it is turned on for the first time.

2. Finish Windows setup.

Follow the on-screen instructions to complete the setup. When setting up, Dell Technologies recommends that you:





- Connect to a network for Windows updates.

NOTE: If connecting to a secured wireless network, enter the password for the wireless network access when prompted.

- If connected to the Internet, sign in with or create a Microsoft account. If not connected to the Internet, create an offline account.
- On the **Support and Protection** screen, enter your contact details.

3. Locate and use Dell apps from the Windows Start menu—Recommended.

Table 1. Locate Dell apps


| Resources | Description |
|---|--|
|  | <p>My Dell</p> <p>Centralized location for key Dell applications, help articles, and other important information about your computer. It also notifies you about the warranty status, recommended accessories, and software updates if available.</p> |
|  | <p>SupportAssist</p> <p>SupportAssist proactively and predictively identifies hardware and software issues on your computer and automates the engagement process with Dell Technical support. It addresses performance and stabilization issues, prevents security threats, monitors, and detects hardware failures. For more information, see <i>SupportAssist for Home PCs User's Guide</i> at Serviceability Tools at the Dell Support Site. Click SupportAssist and then, click SupportAssist for Home PCs.</p> <p>NOTE: In SupportAssist, click the warranty expiry date to renew or upgrade your warranty.</p> |
|  | <p>Dell Update</p> <p>Updates your computer with critical fixes and latest device drivers as they become available. For more information on using Dell Update, search in the Knowledge Base Resource at the Dell Support Site.</p> |
|  | <p>Dell Digital Delivery</p> <p>Download software applications, which are purchased but not preinstalled on your computer. For more information on using Dell Digital Delivery, search in the Knowledge Base Resource at the Dell Support Site.</p> |

Specifications of Dell G15 5530

Dimensions and weight

The following table lists the height, width, depth, and weight of your Dell G15 5530.



Table 2. Dimensions and weight

| Description | Values |
|---|-----------------------|
| Height: | |
| Front height | 21.28 mm (0.83 in.) |
| Rear height | 26.15 mm (1.02 in.) |
| Width | 357.26 mm (14.06 in.) |
| Depth | 274.52 mm (10.80 in.) |
| Weight  NOTE: The weight of your computer depends on the configuration that is offered. | 2.81 kg (6.20 lb) |

Processor

The following table lists the details of the processors supported by your Dell G15 5530.

Table 3. Processor

| Description | Option one | Option two | Option three | Option four |
|---|---|---|---|---|
| Processor type | 13 th Generation Intel Core i5-13450HX | 13 th Generation Intel Core i7-13650HX | 13 th Generation Intel Core i7-13700HX | 13 th Generation Intel Core i9-13900HX |
| Processor wattage | 55 W | 55 W | 55 W | 55 W |
| Processor total core count | 10 | 14 | 16 | 24 |
| Performance-cores | 6 | 6 | 8 | 8 |
| Efficient-cores | 4 | 8 | 8 | 16 |
| Processor total thread counts | 16 | 20 | 24 | 32 |
|  NOTE: Intel® Hyper-Threading Technology is only available on Performance-cores. | | | | |
| Performance-cores frequency | | | | |
| Processor base frequency | 2.40 GHz | 2.60 GHz | 2.10 GHz | 2.20 GHz |
| Maximum turbo frequency | Up to 4.60 GHz | Up to 4.90 GHz | Up to 5 GHz | Up to 5.40 GHz |
| Efficient-cores frequency | | | | |
| Processor base frequency | 1.80 GHz | 1.90 GHz | 1.50 GHz | 1.60 GHz |
| Maximum turbo frequency | 3.40 GHz | 3.60 GHz | 3.70 GHz | 3.90 GHz |
|  NOTE: Processor clock speeds and thermal design power differ according to the thermal mode selected in the My Dell app on your computer. | | | | |
| Processor cache | 20 MB | 24 MB | 30 MB | 36 MB |
| Integrated graphics | Intel UHD Graphics | Intel UHD Graphics | Intel UHD Graphics | Intel UHD Graphics |

Chipset

The following table lists the details of the chipset that is supported in your Dell G15 5530.

Table 4. Chipset

| Description | Values |
|----------------|---|
| Chipset | HM770 |
| Processor | 13 th Generation Intel Core i5/i7/i9 |
| DRAM bus width | 64-bit |
| Flash EPROM | 32 MB |
| PCIe bus | Up to Gen4 |

Operating system

Your Dell G15 5530 supports the following operating systems:

- Windows 11 Professional, 64-bit
- Windows 11 Home, 64-bit
- Ubuntu 20.04 LTS, 64-bit

Memory

The following table lists the memory specifications that are supported by your Dell G15 5530.

Table 5. Memory specifications

| Description | Values |
|---------------------------------|---|
| Memory slots | Two SODIMM slots |
| Memory type | DDR5 |
| Memory speed | 4800 MT/s |
| Maximum memory configuration | 32 GB |
| Minimum memory configuration | 8 GB |
| Memory size per slot | 8 GB or 16 GB |
| Memory configurations supported | <ul style="list-style-type: none">• 8 GB, 1 x 8 GB, DDR5, 4800 MT/s• 16 GB, 1 x 16 GB, DDR5, 4800 MT/s• 16 GB, 2 x 8 GB, DDR5, 4800 MT/s, dual-channel• 32 GB, 2 x 16 GB, DDR5, 4800 MT/s, dual-channel <p>NOTE: When upgrading memory, Dell Technologies recommends replacing memory of the same capacity and speed in both the SODIMM slots to prevent compatibility and reliability issues.</p> <p>Ensure that the BIOS version is 1.6.0 or later when upgrading the memory.</p> |

External ports and slots

The following table lists the external ports and slots of your Dell G15 5530.

Table 6. External ports and slots

| Description | Values |
|-------------------|---|
| Network port | One RJ-45 port |
| USB ports | <ul style="list-style-type: none">• Three USB 3.2 Gen 1 ports• One USB 3.2 Gen 2 (Type-C) with DisplayPort |
| Audio port | One universal audio jack |
| Video port(s) | One HDMI 2.1 port |
| Media-card reader | Not supported |

Table 6. External ports and slots (continued)

| Description | Values |
|---------------------|--|
| Power-adaptor port | One 7.4 mm x 5.1 mm power-adaptor port |
| Security-cable slot | Not supported |

Internal slots

The following table lists the internal slots of your Dell G15 5530.

Table 7. Internal slots

| Description | Values |
|-------------|--|
| M.2 | <ul style="list-style-type: none"> One M.2 2230 slot for Wi-Fi and Bluetooth combo card Two M.2 2230/2280 slots for solid-state drives <p>NOTE: To learn more about the features of different types of M.2 cards, search in the Knowledge Base Resource at Dell Support Site.</p> |

Ethernet

The following table lists the wired Ethernet Local Area Network (LAN) specifications of your Dell G15 5530.

Table 8. Ethernet specifications

| Description | Values |
|---------------|--|
| Model | Realtek RTL8111H PCI-e 1 Gigabit Ethernet controller |
| Transfer rate | 10/100/1000 Mbps |

Wireless module

The following table lists the Wireless Local Area Network (WLAN) module that is supported on your Dell G15 5530.

Table 9. Wireless module specifications

| Description | Values |
|---------------------------|--|
| Model number | Intel AX201 |
| Transfer rate | 2400 Mbps |
| Frequency bands supported | 2.4 GHz/5 GHz |
| Wireless standards | <ul style="list-style-type: none"> Wi-Fi 802.11a/b/g Wi-Fi 4 (Wi-Fi 802.11n) Wi-Fi 5 (Wi-Fi 802.11ac) Wi-Fi 6 (Wi-Fi 802.11ax) |
| Encryption | <ul style="list-style-type: none"> 64-bit/128-bit WEP AES-CCMP TKIP |

Table 9. Wireless module specifications (continued)

| Description | Values |
|-------------------------|---------------|
| Bluetooth wireless card | Bluetooth 5.2 |

Audio

The following table lists the audio specifications of your Dell G15 5530.

Table 10. Audio specifications

| Description | Values | |
|----------------------------|-----------------------------------|-----------------|
| Audio controller | Realtek ALC3204 | |
| Stereo conversion | Supported | |
| Internal audio interface | High definition audio | |
| External audio interface | One universal audio jack | |
| Number of speakers | Two | |
| Internal-speaker amplifier | Supported | |
| External volume controls | Keyboard shortcut controls | |
| Speaker output: | | |
| | Average | 2 x 2 W = 4 W |
| | Peak | 2 x 2.5 W = 5 W |
| Microphone | One microphone in camera assembly | |

Storage

This section lists the storage options on your Dell G15 5530.

Your Dell G15 5530 supports one of the following storage configurations:

- One M.2 2230 or M.2 2280 solid-state drive
- Two M.2 2230 or M.2 2280 solid-state drives

The primary drive of your Dell G15 5530 is installed in solid-state drive slot one.

Table 11. Storage specifications

| Storage type | Interface type | Capacity |
|----------------------------|-------------------|------------|
| M.2 2230 solid-state drive | PCIe NVMe Gen4 x4 | Up to 1 TB |
| M.2 2280 solid-state drive | PCIe NVMe Gen4 x4 | Up to 2 TB |

Keyboard

The following table lists the keyboard specifications of your Dell G15 5530.

Table 12. Keyboard specifications

| Description | Values |
|--------------------|---|
| Keyboard type | <ul style="list-style-type: none"> ● Single-color backlit (white) keyboard ● Single-color backlit (hot coral) keyboard ● Four-zone RGB backlit keyboard |
| Keyboard layout | QWERTY |
| Number of keys | <ul style="list-style-type: none"> ● United States and Canada: 101 keys ● United Kingdom: 102 keys ● Japan: 105 keys |
| Keyboard size | X=18.70 mm key pitch Y=18.05 mm key pitch |
| Keyboard shortcuts | <p>Some keys on your keyboard have two symbols on them. These keys can be used to type alternate characters or to perform secondary functions. To type the alternate character, press Shift and the desired key. To perform secondary functions, press Fn and the desired key.</p> <p>NOTE: You can define the primary behavior of the function keys (F1–F12) changing Function Key Behavior in the BIOS setup program.</p> <p>NOTE: If Copilot in Windows is not available on your computer, pressing the Copilot key launches Windows search. For more information about Copilot in Windows, search in the Knowledge Base Resource at the Dell Support site.</p> |

Keyboard shortcuts

NOTE: Keyboard characters may differ depending on the keyboard language configuration. Keys used for shortcuts remain the same across all language configurations.



































Some keys on your keyboard have two symbols on them. These keys can be used to type alternate characters or to perform secondary functions. The symbol shown on the lower part of the key refers to the character that is typed out when the key is pressed. If you press **Shift** and the key, the symbol shown on the upper part of the key is typed out. For example, if you press **2**, **2** is typed out; if you press **Shift + 2**, **@** is typed out.

The keys **F1** to **F12** at the top row of the keyboard are function keys for multi-media control, as indicated by the icon at the bottom of the key. Press the function key to invoke the task represented by the icon. For example, pressing **F1** mutes the audio (refer to the table below).

However, if the function keys **F1** to **F12** are needed for specific software applications, multi-media functionality can be disabled by pressing **fn + Esc**. Subsequently, multi-media control can be invoked by pressing **fn** and the respective function key. For example, mute audio by pressing **fn + F1**.

























NOTE: You can also define the primary behavior of the function keys (**F1** to **F12**) by changing **Function Key Behavior** in the BIOS Setup program.

Table 13. List of keyboard shortcuts

| Function key | Redefined key (for multimedia control) | Primary behavior |
|---|---|--|
|  |  +  | Mute audio |
|  |  +  | Decrease volume |
|  |  +  | Increase volume |
|  |  +  | Play/Pause |
|  |  +  | Toggle keyboard backlight (optional) |
|  |  +  | Decrease brightness |
|  |  +  | Increase brightness |
|  |  +  | Switch to external display |
|  |  +  | Search/G key (optional) |
|  |  +  | Print screen |
|  |  +  | Home |
|  |  +  | End |
|  | | Disable or enable the Windows key which activates the Windows Start screen when the Windows key is pressed. NOTE: Disabling the Windows key helps you to avoid accidental presses of the Windows key during gaming sessions. |

The **Fn** key is also used with selected keys on the keyboard to invoke other secondary functions.

Table 14. Secondary behavior

| Function key | Secondary behavior |
|---|---|
|  +  | Turn off/on wireless |
|  +  | Pause/Break |
|  +  | Insert |
|  +  | Sleep |
|  +  | Toggle between power and battery-status light/hard-drive activity light |
|  +  | System request |
|  +  | Open application menu |
|  +  | Toggle fn-key lock |
|  +  | Page up |
|  +  | Page down |
|  +  | Home |
|  +  | End |

Camera

The following table lists the camera specifications of your Dell G15 5530.

Table 15. Camera specifications

| Description | Values |
|--------------------|------------------------|
| Number of cameras | One |
| Camera type | HD RGB camera |
| Camera location | Front camera |
| Camera sensor type | CMOS sensor technology |

Table 15. Camera specifications (continued)

| Description | | Values |
|------------------------|-------------|---------------------------|
| Camera resolution: | | |
| | Still image | 0.92 megapixel |
| | Video | 1280 x 720 (HD) at 30 fps |
| Diagonal viewing angle | | 78.6 degrees |

Touchpad

The following table lists the touchpad specifications of your Dell G15 5530.

Table 16. Touchpad specifications

| Description | | Values |
|----------------------|------------|---|
| Touchpad resolution: | | |
| | Horizontal | 1229 |
| | Vertical | 689 |
| Touchpad dimensions: | | |
| | Horizontal | 105 mm (4.13 in.) |
| | Vertical | 60 mm (2.36 in.) |
| Touchpad gestures | | <p>For more information about the touchpad gestures that are available on:</p> <ul style="list-style-type: none"> Windows, see the Microsoft Knowledge Base article at Microsoft Support Site. Ubuntu, see Ubuntu Support Site. |


Power adapter

The following table lists the power adapter specifications of your Dell G15 5530.

Table 17. Power-adapter specifications

| Description | Option one | Option two | Option three |
|---------------------------|---|--------------------|--------------------|
| Type | 180 W <i>i</i> NOTE: The availability of computer configurations with a 180 W adapter may vary and may not be available in your specific country or region. | 240 W | 330 W |
| Connector dimensions: | | | |
| | External diameter | 7.40 mm (0.29 in.) | 7.40 mm (0.29 in.) |
| | Internal diameter | 5.10 mm (0.20 in.) | 5.10 mm (0.20 in.) |
| Power-adapter dimensions: | | | |

Table 17. Power-adapter specifications (continued)

| Description | | Option one | Option two | Option three |
|---|-----------|--------------------------------|--------------------------------|--------------------------------|
| | Height | 30 mm (1.18 in.) | 25.40 mm (1 in.) | 43 mm (1.69 in.) |
| | Width | 76.20 mm (3 in.) | 100 mm (3.94 in.) | 100 mm (3.94 in.) |
| | Depth | 155 mm (6.10 in.) | 200 mm (7.87 in.) | 200 mm (7.87 in.) |
| Input voltage | | 100 VAC x 240 VAC | 100 VAC x 240 VAC | 100 VAC x 240 VAC |
| Input frequency | | 50 Hz x 60 Hz | 50 Hz x 60 Hz | 50 Hz x 60 Hz |
| Input current (maximum) | | 2.34 A | 3.50 A | 4.40 A |
| Output current (continuous) | | 2.34 A | 12.31 A | 16.92 A |
| Rated output voltage | | 19.50 VDC | 19.50 VDC | 19.50 VDC |
| Temperature range: | | | | |
| | Operating | 0°C to 40°C (32°F to 104°F) | 0°C to 40°C (32°F to 104°F) | 0°C to 40°C (32°F to 104°F) |
| | Storage | -40°C to 70°C (-40°F to 158°F) | -40°C to 70°C (-40°F to 158°F) | -40°C to 70°C (-40°F to 158°F) |
|  CAUTION: Operating and storage temperature ranges may differ among components, so operating or storing the device outside these ranges may impact the performance of specific components. | | | | |

Battery

The following table lists the battery specifications of your Dell G15 5530.

Table 18. Battery specifications

| Description | | Option one | Option two |
|--------------------------|-----------|---|---|
| Battery type | | 3-cell, 56 Wh, Lithium-ion, ExpressCharge Boost | 6-cell, 86 Wh, Lithium-ion, ExpressCharge Boost |
| Battery voltage | | 11.40 VDC | 11.40 VDC |
| Battery weight (maximum) | | 0.25 Kg (0.56 lb) | 0.34 kg (0.75 lb) |
| Battery dimensions: | | | |
| | Height | 7.56 mm (0.30 in.) | 7.56 mm (0.30 in.) |
| | Width | 77.70 mm (3.06 in.) | 77.70 mm (3.06 in.) |
| | Depth | 295.20 mm (11.62 in.) | 295.20 mm (11.62 in.) |
| Temperature range: | | | |
| | Operating | <ul style="list-style-type: none"> Charge: 0°C to 50°C (32°F to 122°F) Discharge: 0°C to 60°C (32°F to 140°F) | <ul style="list-style-type: none"> Charge: 0°C to 50°C (32°F to 122°F) Discharge: 0°C to 60°C (32°F to 140°F) |
| | Storage | -20°C to 65°C (-4°F to 149°F) | -20°C to 65°C (-4°F to 149°F) |

Table 18. Battery specifications (continued)

| Description | Option one | Option two |
|--|--|--|
| Battery operating time | Varies depending on operating conditions and can significantly reduce under certain power-intensive conditions. | Varies depending on operating conditions and can significantly reduce under certain power-intensive conditions. |
| Battery charging time (approximate) | <ul style="list-style-type: none"> Express Charge Method: 2 hours Standard Charge/Predominately AC User Charge Method: 3 hours Express Charge Boost Charge Method (Fast Charge for Initial 35%): From 0% up to 35% in as little as 20 minutes | <ul style="list-style-type: none"> Express Charge Method: 2 hours Standard Charge/Predominately AC User Charge Method: 3 hours Express Charge Boost Charge Method (Fast Charge for Initial 35%): From 0% up to 35% in as little as 20 minutes |
| Coin-cell battery | Not supported | Not supported |
| <p>⚠ CAUTION: Operating and storage temperature ranges may differ among components, so operating or storing the device outside these ranges may impact the performance of specific components.</p> <p>⚠ CAUTION: Dell Technologies recommends that you charge the battery regularly for optimal power consumption. If your battery charge is depleted, connect the power adapter, turn on your computer, and then restart your computer to reduce the power consumption.</p> | | |

Display

The following table lists the display specifications of your Dell G15 5530.

Table 19. Display specifications

| Description | Option one | Option two | Option three | Option four |
|---|----------------------------|--|--|--|
| Display type | Full High Definition (FHD) | Full High Definition (FHD), ComfortView Plus | Full High Definition (FHD), ComfortView Plus | Quad-High Definition (QHD), ComfortView Plus |
| Display-panel technology | Wide-Viewing Angle (WVA) | Wide-Viewing Angle (WVA) | Wide-Viewing Angle (WVA) | Wide-Viewing Angle (WVA) |
| Display-panel dimensions (active area): | | | | |
| Height | 193.59 mm (7.62 in.) | 193.59 mm (7.62 in.) | 193.59 mm (7.62 in.) | 193.59 mm (7.62 in.) |
| Width | 344.16 mm (13.55 in.) | 344.16 mm (13.55 in.) | 344.16 mm (13.55 in.) | 344.16 mm (13.55 in.) |
| Diagonal | 395 mm (15.60 in.) | 395 mm (15.60 in.) | 394.87 mm (15.60 in.) | 394.87 mm (15.60 in.) |
| Display-panel native resolution | 1920 x 1080 | 1920 x 1080 | 1920 x 1080 | 2560 x 1440 |
| Luminance (typical) | 250 nits | 300 nits | 300 nits | 400 nits |
| Megapixels | 2.07 | 2.07 | 2.07 | 3.68 |
| Color gamut | 45% NTSC (typical) | 100% sRGB (typical) | 100% sRGB (typical) | 99% DCI-P3 (typical) |

Table 19. Display specifications (continued)

| Description | Option one | Option two | Option three | Option four |
|-----------------------------|--|---|---|---|
| Pixels Per Inch (PPI) | 141 | 141 | 141 | 188 |
| Contrast ratio (typical) | <ul style="list-style-type: none"> 600:1 (minimum) 800:1 (typical) | <ul style="list-style-type: none"> 800:1 (minimum) 1000:1 (typical) | <ul style="list-style-type: none"> 800:1 (minimum) 1000:1 (typical) | <ul style="list-style-type: none"> 800:1 (minimum) 1000:1 (typical) |
| Response time (maximum) | <ul style="list-style-type: none"> Tr+Tf: 25 ms (typical) Tr+Tf: 35 ms (maximum) | <ul style="list-style-type: none"> GtG with Overdrive: 3 ms (typical) GtG without Overdrive: 8 ms (typical) | GtG with Overdrive: 1 ms (typical) | GtG with Overdrive: 2 ms (typical) |
| Refresh rate | 120 Hz | 165 Hz | 360 Hz | 240 Hz |
| Horizontal view angle | +/- 85 degrees (typical) | +/- 85 degrees (typical) | +/- 85 degrees (typical) | +/- 85 degrees (typical) |
| Vertical view angle | +/- 85 degrees (typical) | +/- 85 degrees (typical) | +/- 85 degrees (typical) | +/- 85 degrees (typical) |
| Pixel pitch | 0.17925 mm x 0.17925 mm | 0.17925 mm x 0.17925 mm | 0.17925 mm x 0.17925 mm | 0.13446 mm x 0.13446 mm |
| Power consumption (maximum) | 4.60 W | 6 W | 7.60 W | 8.55 W |
| Anti-glare vs glossy finish | Anti-glare | Anti-glare | Anti-glare | Anti-glare |
| Touch options | No | No | No | No |

GPU—Integrated

The following table lists the specifications of the integrated Graphics Processing Unit (GPU) supported by your Dell G15 5530.

Table 20. GPU—Integrated

| Controller | Memory size | Processor |
|--------------------|----------------------|---|
| Intel UHD Graphics | Shared system memory | 13 th Generation Intel Core i5/i7/i9 |

GPU—Discrete

The following table lists the specifications of the discrete Graphics Processing Unit (GPU) supported by your Dell G15 5530.

Table 21. GPU—Discrete


| Controller | Memory size | Memory type |
|-------------------------|-------------|-------------|
| NVIDIA GeForce RTX 3050 | 6 GB | DDR6 |
| NVIDIA GeForce RTX 4050 | 6 GB | DDR6 |
| NVIDIA GeForce RTX 4060 | 8 GB | DDR6 |

Operating and storage environment

This table lists the operating and storage specifications of your Dell G15 5530.

Airborne contaminant level: G1 as defined by ISA-S71.04-1985


Table 22. Computer environment

| Description | Operating | Storage |
|--|--|--|
| Temperature range | 0°C to 35°C (32°F to 95°F) | -40°C to 65°C (-40°F to 149°F) |
| Relative humidity (maximum) | 10% to 90% (non-condensing) | 0% to 95% (non-condensing) |
| Vibration (maximum)* | 0.66 GRMS | 1.30 GRMS |
| Shock (maximum) | 110 G† | 160 G† |
| Altitude range | -15.2 m to 3048 m (4.64 ft to 5518.4 ft) | -15.2 m to 10668 m (4.64 ft to 19234.4 ft) |
|  CAUTION: Operating and storage temperature ranges may differ among components, so operating or storing the device outside these ranges may impact the performance of specific components. | | |

* Measured using a random vibration spectrum that simulates the user environment.

† Measured using a 2 ms half-sine pulse.

ComfortView Plus

 **WARNING: Prolonged exposure to blue light from the display may lead to long-term effects such as eye strain, eye fatigue, or damage to the eyes.**

Blue light is a color in the light spectrum which has a short wavelength and high energy. Chronic exposure to blue light, particularly from digital sources may disrupt sleep patterns and cause long-term effects such as eye strain, eye fatigue, or damage to the eyes.

The display on this computer is designed to minimize blue light and complies with TÜV Rheinland's requirement for low blue light displays.

Low blue light mode is enabled at the factory, so no further configuration is necessary.










To reduce the risk of eye strain, it is also recommended that you:

- Position the display at a comfortable viewing distance between 20 and 28 inches (50 cm and 70 cm) from your eyes.
- Blink frequently to moisten your eyes, wet your eyes with water, or apply suitable eye drops.
- Take an extended break for 20 minutes every two hours.
- Look away from your display, and gaze at a distant object at 20 ft (609.60 cm) away for at least 20 seconds during each break.

Working inside your computer


Safety instructions

Use the following safety guidelines to protect your computer from potential damage and to ensure your personal safety. Unless otherwise noted, each procedure in this document assumes that you have read the safety information that shipped with your computer.



-  **WARNING:** Before working inside your computer, read the safety information that is shipped with your computer. For more safety best practices, see [Dell Regulatory Compliance Home Page](#).
-  **WARNING:** Disconnect your computer from all power sources before opening the computer cover or panels. After you finish working inside the computer, replace all covers, panels, and screws before connecting your computer to an electrical outlet.
-  **CAUTION:** To avoid damaging the computer, ensure that the work surface is flat, dry, and clean.
-  **CAUTION:** You should only perform troubleshooting and repairs as authorized or directed by the Dell technical support team. Damage due to servicing that is not authorized by Dell is not covered by your warranty. See the safety instructions that is shipped with the product or at [Dell Regulatory Compliance Home Page](#).
-  **CAUTION:** Before touching anything inside your computer, ground yourself by touching an unpainted metal surface, such as the metal at the back of the computer. While you work, periodically touch an unpainted metal surface to dissipate static electricity which could harm internal components.
-  **CAUTION:** To avoid damaging the components and cards, handle them by their edges, and avoid touching the pins and the contacts.
-  **CAUTION:** When you disconnect a cable, pull it by its connector or its pull tab, not the cable itself. Some cables have connectors with locking tabs or thumbscrews that you must disengage before disconnecting the cable. When disconnecting cables, keep them evenly aligned to avoid bending the connector pins. When connecting cables, ensure that the connector on the cable is correctly oriented and aligned with the port.
-  **CAUTION:** Press and eject any installed card from the media-card reader.
-  **CAUTION:** Exercise caution when handling rechargeable Li-ion batteries in laptops. Swollen batteries should not be used and should be replaced and disposed properly.

Before working inside your computer

About this task

 **NOTE:** The images in this document may differ from your computer depending on the configuration you ordered.

Steps

1. Save and close all open files and exit all open applications.
2. Shut down your computer. For Windows operating system, click **Start** >  **Power** > **Shut down**.
 -  **NOTE:** If you are using a different operating system, see the documentation of your operating system for shut-down instructions.
3. Turn off all the attached peripherals.
4. Disconnect your computer and all attached devices from their electrical outlets.

5. Disconnect all attached network devices and peripherals, such as keyboard, mouse, and monitor from your computer.

 **CAUTION: To disconnect a network cable, unplug the cable from your computer.**

6. Remove any media card and optical disc from your computer, if applicable.

Safety precautions

This section details the primary steps to be followed before performing any disassembly instructions.

Observe the following safety precautions before you perform any installation or break-fix procedures involving disassembly or reassembly:

- Turn off the computer and all attached peripherals.
- Disconnect the computer from AC power.
- Disconnect all network cables and peripherals from the computer.
- Use an ESD field service kit when working inside any to avoid electrostatic discharge (ESD) damage.
- Place the removed component on an anti-static mat after removing it from the computer.
- Wear shoes with nonconductive rubber soles to reduce the chance of getting electrocuted.
- Unplugging, pressing, and holding the power button for 15 seconds should discharge residual power in the system board.

Standby power

Dell products with standby power must be unplugged before you open the back cover. Systems that are equipped with standby power are powered while turned off. The internal power enables the computer to be remotely turned on (Wake-on-LAN) and suspended into a sleep mode and has other advanced power management features.

Bonding

Bonding is a method for connecting two or more grounding conductors to the same electrical potential. This is done by using a field service electrostatic discharge (ESD) kit. When connecting a bonding wire, ensure that it is connected to bare metal and never to a painted or nonmetal surface. Ensure that the wrist strap is secure and in full contact with your skin. Remove all jewelry, watches, bracelets, or rings before grounding yourself and the equipment.

Electrostatic discharge—ESD protection

ESD is a major concern when you handle electronic components, especially sensitive components such as expansion cards, processors, memory modules, and system boards. A slight charge can damage circuits in ways that may not be obvious, such as intermittent problems or a shortened product life span. As the industry pushes for lower power requirements and increased density, ESD protection is an increasing concern.

Two recognized types of ESD damage are catastrophic and intermittent failures.

- **Catastrophic** – Catastrophic failures represent approximately 20 percent of ESD-related failures. The damage causes an immediate and complete loss of device functionality. An example of catastrophic failure is a memory module that has received a static shock and immediately generates a "No POST/No Video" symptom with a beep code that is emitted for missing or nonfunctional memory.
- **Intermittent** – Intermittent failures represent approximately 80 percent of ESD-related failures. The high rate of intermittent failures means that most of the time when damage occurs, it is not immediately recognizable. The memory module receives a static shock, but the tracing is merely weakened and does not immediately produce outward symptoms that are related to the damage. The weakened trace may take weeks or months to melt, and in the meantime may cause degradation of memory integrity, intermittent memory errors, and so on.

Intermittent failures that are also called latent or "walking wounded" are difficult to detect and troubleshoot.

Perform the following steps to prevent ESD damage:


- Use a wired ESD wrist strap that is properly grounded. Wireless anti-static straps do not provide adequate protection. Touching the chassis before handling parts does not ensure adequate ESD protection on parts with increased sensitivity to ESD damage.
- Handle all static-sensitive components in a static-safe area. If possible, use anti-static floor pads and workbench pads.
- When unpacking a static-sensitive component from its shipping carton, do not remove the component from the anti-static packing material until you are ready to install the component. Before unwrapping the anti-static packaging, use the anti-

static wrist strap to discharge the static electricity from your body. For more information about the wrist strap and ESD wrist strap tester, see [Components of an ESD Field Service Kit](#).

- Before transporting a static-sensitive component, place it in an anti-static container or packaging.

ESD Field Service kit

The unmonitored field service kit is the most commonly used service kit. Each Field Service kit includes three main components: anti-static mat, wrist strap, and bonding wire.

 **CAUTION: It is critical to keep ESD-sensitive devices away from internal parts that are insulated and often highly charged, such as plastic heat sink casings.**

Working Environment

Before deploying the ESD Field Service kit, assess the situation at the customer location. For example, deploying the kit for a server environment is different than for a desktop or laptop environment. Servers are typically installed in a rack within a data center; desktops or laptops are typically placed on office desks or cubicles. Always look for a large open flat work area that is free of clutter and large enough to deploy the ESD kit with additional space to accommodate the type of computer that is being repaired. The workspace should also be free of insulators that can cause an ESD event. On the work area, insulators such as styrofoam and other plastics should always be moved at least 12 inches or 30 centimeters away from sensitive parts before physically handling any hardware components.


ESD Packaging

All ESD-sensitive devices must be shipped and received in static-safe packaging. Metal, static-shielded bags are preferred. However, you should always return the damaged component using the same ESD bag and packaging that the new part arrived in. The ESD bag should be folded over and taped shut and all the same foam packing material should be used in the original box that the new part arrived in. ESD-sensitive devices should be removed from packaging only at an ESD-protected work surface, and parts should never be placed on top of the ESD bag because only the inside of the bag is shielded. Always place parts in your hand, on the anti-static mat, in the computer, or inside an ESD bag.

Components of an ESD Field Service kit

The components of an ESD Field Service kit are:

- **Anti-Static Mat** – The anti-static mat is dissipative and parts can be placed on it during service procedures. When using an anti-static mat, your wrist strap should be snug and the bonding wire should be connected to the anti-static mat and to any bare metal on the computer being worked on. Once deployed properly, service parts can be removed from the ESD bag and placed directly on the anti-static mat. ESD-sensitive items are safe in your hand, on the anti-static mat, in the computer, or inside an ESD bag.
- **Wrist Strap and Bonding Wire** – The wrist strap and bonding wire can be either directly connected between your wrist and bare metal on the hardware if the anti-static mat is not required, or connect to the anti-static mat to protect hardware that is temporarily placed on the mat. The physical connection of the wrist strap and bonding wire between your skin, the anti-static mat, and the hardware is known as bonding. Use only Field Service kits with a wrist strap, anti-static mat, and bonding wire. Never use wireless wrist straps. Always be cautious that the internal wires of a wrist strap are prone to damage from normal wear and tear, and must be checked regularly with a wrist strap tester in order to avoid accidental ESD hardware damage. It is recommended to test the wrist strap and bonding wire at least once per week.
- **ESD Wrist Strap Tester** – The wires inside an ESD strap are prone to damage over time. When using an unmonitored kit, it is a best practice to regularly test the strap prior to each service, and at a minimum, test once per week. A wrist strap tester is the best method for doing this test. To perform the test, plug the bonding-wire of the wrist-strap into the tester while it is strapped to your wrist and push the button to test. A green LED is lit if the test is successful; a red LED is lit and an alarm sounds if the test fails.


 **NOTE:** It is recommended to always use the traditional wired ESD grounding wrist strap and protective anti-static mat when servicing Dell products. In addition, it is critical to keep sensitive parts separate from all insulator parts while servicing the computer.

Transporting sensitive components

When transporting ESD sensitive components such as replacement parts or parts to be returned to Dell, it is critical to place these parts in anti-static bags for safe transport.

After working inside your computer


About this task

 **CAUTION:** Leaving stray or loose screws inside your computer may severely damage your computer.

Steps

1. Replace all screws and ensure that no stray screws remain inside your computer.
2. Connect any external devices, peripherals, or cables you removed before working on your computer.
3. Replace any media cards, discs, or any other components that you removed before working on your computer.
4. Connect your computer and all attached devices to their electrical outlets.
5. Turn on your computer.

BitLocker

 **CAUTION:** If BitLocker is not suspended before updating the BIOS, the BitLocker key is not recognized the next time you reboot the computer. You will then be prompted to enter the recovery key to progress, and the system displays a prompt for the recovery key on each reboot. If the recovery key is not known, this can result in data loss or an operating system reinstall. For more information, see Knowledge Article: [updating the BIOS on Dell systems with BitLocker enabled](#).

The installation of the following components triggers BitLocker:


- Hard disk drive or solid-state drive
- System board


Recommended tools

The procedures in this document may require the following tools:

- Phillips screwdriver #0
- Phillips screwdriver #1
- Plastic scribe

Screw list

 **NOTE:** When removing screws from a component, it is recommended to note the screw type and the quantity of screws, and then place them in a screw storage box. This is to ensure that the correct number of screws and correct screw type is restored when the component is replaced.

 **NOTE:** Some computers have magnetic surfaces. Ensure that the screws are not left attached to such surfaces when replacing a component.

 **NOTE:** Screw color may vary depending on the configuration ordered.

Table 23. Screw list
























| Component | Screw type | Quantity | Screw image |
|--------------------------------|------------|----------|---|
| Base cover | M2x5 | 6 |  |
| Battery | M2x4 | 4 |  |
| Solid-state drive (SSD slot 1) | M2x4 | 2 |  |
| Solid-state drive (SSD slot 2) | M2x4 | 2 |  |
| Wireless card | M2x4 | 1 |  |
| Touchpad bracket | M2x2 | 3 |  |
| Touchpad | M2x2 | 4 |  |
| Rear cover | M2x4 | 2 |  |
| Rear cover | M2x5 | 4 |  |
| Display hinges | M2.5x4 | 8 |  |
| Keyboard-controller board | M2x2 | 1 |  |
| Power-adaptor port | M2x5 | 2 |  |
| System board | M2x5 | 7 |  |
| System board | M2x4 | 1 |  |
| USB board | M2x4 | 2 |  |
| USB board | M2x3 | 1 |  |
| Ethernet and audio board | M2x4 | 2 |  |
| Ethernet and audio board | M2x3 | 1 |  |

Table 23. Screw list (continued)

| Component | Screw type | Quantity | Screw image |
|---------------------------------------|-------------------|-----------------|---|
| Left fan (fan and heat-sink assembly) | M2x4 | 1 |  |
| Fan and heat-sink assembly | M2x4 | 7 |  |
| Power-button board bracket | M2x2 | 2 |  |
| Power button | M2x2 | 1 |  |

Major components of Dell G15 5530


The following image shows the major components of Dell G15 5530.



- 1. Base cover
- 3. M.2 solid-state drive
- 5. M.2 solid-state drive
- 7. Ethernet and audio board

- 2. Fan and heat-sink assembly
- 4. M.2 solid-state drive thermal shield
- 6. Memory module
- 8. System board


- 9. Battery
- 10. Speakers
- 11. Touchpad
- 12. Touchpad bracket
- 13. Palm-rest and keyboard assembly
- 14. Display assembly
- 15. USB board
- 16. Rear cover
- 17. Power-adapter port bracket
- 18. Power button
- 19. Power-button board
- 20. Type-C bracket
- 21. Wireless card
- 22. Wireless-card bracket
- 23. Power-adapter port

 **NOTE:** Dell provides a list of components and their part numbers for the original system configuration purchased. These parts are available according to warranty coverages purchased by the customer. Contact your Dell sales representative for purchase options.

Removing and installing Customer Replaceable Units (CRUs)

The replaceable components in this chapter are Customer Replaceable Units (CRUs).

 **CAUTION:** Customers can replace only the Customer Replaceable Units (CRUs) following the safety precautions and replacement procedures.

 **NOTE:** The images in this document may differ from your computer depending on the configuration you ordered.

Base cover

Removing the base cover

Prerequisites

1. Follow the procedure in [Before working inside your computer](#).

About this task

The following images indicate the location of the base cover and provide a visual representation of the removal procedure.



6x
M2x5



4x





Steps

1. Remove the six screws (M2x5) that secure the base cover to the palm-rest and keyboard assembly.
2. Loosen the four captive screws that secure the base cover to the palm-rest and keyboard assembly.
 - i** **NOTE:** Loosening the two captive screws located in the front of the computer creates a gap which can be used to pry and lift the base cover off the palm-rest and keyboard assembly.
3. Starting from the gap created at the left-bottom corner, pry open the base cover. Work your way around the bottom edge and bottom-right corner of the base cover.
4. Lift the base cover off the palm-rest and keyboard assembly.
 - i** **NOTE:** The following steps are applicable only if you want to further remove any other component from your computer.
5. Using the pull tab, disconnect the battery cable from the system board.
6. Turn your computer over and press the power button for 20 seconds to drain the flea power.

Installing the base cover


Prerequisites

If you are replacing a component, remove the existing component before performing the installation procedure.

About this task

The following images indicate the location of the base cover and provide a visual representation of the installation procedure.





Steps

1. Connect the battery cable to the system board, if the battery cable had been previously disconnected.
2. Align the screw holes on the base cover with the screw holes on the palm-rest and keyboard assembly, and then snap the base cover into place.
3. Replace the six screws (M2x5) that secure the base cover to the palm-rest and keyboard assembly.
4. Tighten the four captive screws that secure the base cover to the palm-rest and keyboard assembly.

Next steps

1. Follow the procedure in [After working inside your computer](#).

Solid-state drive

Removing the solid-state drive

Prerequisites


1. Follow the procedure in [Before working inside your computer](#).
2. Remove the [base cover](#).


About this task

NOTE: Your computer has two M.2 solid-state drive slots, both located on the system board adjacent to the left fan. The procedure to remove a solid-state drive from slot 1 and slot 2 are exactly the same.

NOTE: Depending on the configuration ordered, a 2230 or 2280 solid-state drive may be installed in your computer.

The following image(s) indicates the location of M.2 2230 solid-state drive or the M.2 2280 solid-state drive and provides a visual representation of their respective removal procedures.





Steps

1. Remove the two screws (M2x4) that secure the thermal shield to the solid-state drive and the system board.
2. Lift the thermal shield off the palm-rest and keyboard assembly.
3. Slide and lift the solid-state drive off the M.2 slot on the system board.

Installing the solid-state drive

Prerequisites

If you are replacing a component, remove the existing component before performing the installation procedure.

About this task

- i** **NOTE:** Your computer has two M.2 solid-state drive slots, both located on the system board adjacent to the left fan. The procedure to remove a solid-state drive from slot 1 and slot 2 are exactly the same.
- i** **NOTE:** Depending on the configuration ordered, a M.2 2230 or 2280 solid-state drive may be installed into both slot 1 and 2. If you are installing a solid-state drive into slot 2 by yourself, only a M.2 2280 solid-state drive, paired with a Dell thermal shield is recommended.


The following image(s) indicates the location of the M.2 2230 solid-state drive or the M.2 2280 solid-state drive and provides a visual representation of their respective installation procedures.



2x
M2x4



2x
M2x4



Steps

1. Align the notch on the solid-state drive with the tab on the M.2 card slot.
2. Slide the solid-state drive into the M.2 card slot.
3. Place the thermal shield on the solid-state drive.
4. Align the screw holes on the thermal shield with the screw holes on the solid-state drive and system board.
5. Replace the two screws (M2x4) that secure the thermal shield to the solid-state drive and the system board.

Next steps

1. Install the [base cover](#).

2. Follow the procedure in [After working inside your computer](#).

Wireless card


Removing the wireless card

Prerequisites

1. Follow the procedure in [Before working inside your computer](#).
2. Remove the [base cover](#).

About this task

The following image indicates the location of the wireless card and provides a visual representation of the removal procedure.



Steps

1. Remove the screw (M2x4) that secures the wireless card to the system board.
2. Lift the bracket off the wireless card.
3. Disconnect the antenna cables from the wireless card.
4. Slide and remove the wireless card from the M.2 wireless card slot.


Installing the wireless card

Prerequisites

If you are replacing a component, remove the existing component before performing the installation procedure.

About this task

The following image indicates the location of the wireless card and provides a visual representation of the installation procedure.



Steps

1. Connect the antenna cables to the wireless card.

The following table provides the antenna-cable color scheme for the wireless card supported by your computer.

Table 24. Antenna-cable color scheme

| Connectors on the wireless card | Antenna-cable color |
|---------------------------------|---------------------|
| Main (white triangle) | White |
| Auxiliary (black triangle) | Black |

2. Align the notch on the wireless card with the tab on the M.2 wireless card slot and insert the wireless card at an angle into the M.2 card slot.
3. Place and align the wireless-card bracket on the wireless card.
4. Replace the screw (M2x4) that secures the wireless card to the system board.

Next steps

1. Install the [base cover](#).
2. Follow the procedure in [After working inside your computer](#).

Memory

Removing the memory module


Prerequisites

1. Follow the procedure in [Before working inside your computer](#).
2. Remove the [base cover](#).

About this task

The following image indicates the location of the memory modules and provides a visual representation of the removal procedure.

CAUTION: To prevent damage to the memory module, hold the memory module by the edges. Do not touch the components or metallic contacts on the memory module as electrostatic discharge (ESD) can inflict severe damage on the components. To read more about ESD protection, see [Electrostatic discharge—ESD protection](#).



Steps

1. Gently lift the transparent Mylar.
2. Use your fingertips to carefully spread apart the securing-clips on each end of the memory-module slot until the memory module pops up.
3. Remove the memory module from the memory-module slot.

NOTE: Repeat step 1 and step 2 if there is a second memory module installed on your computer.

4. Lower the transparent Mylar back to its original position.

Installing the memory module


Prerequisites

If you are replacing a component, remove the existing component before performing the installation procedure.

About this task

The following image indicates the location of the memory module and provides a visual representation of the installation procedure.

CAUTION: To prevent damage to the memory module, hold the memory module by the edges. Do not touch the components or metallic contacts on the memory module as electrostatic discharge (ESD) can inflict severe damage on the components. To read more about ESD protection, see [Electrostatic discharge—ESD protection](#).



Steps

1. Gently lift the transparent Mylar.
2. Align the notch on the memory module with the tab on the memory-module slot.
3. Slide the memory module into the memory-module slot.
4. Press the memory module down until it clicks into place.

NOTE: If you do not hear the click, remove the memory module and reinstall it.

NOTE: Repeat step 1 to step 3 to install a second memory module into your computer, if applicable.

5. Lower the transparent Mylar back to its original position.

Next steps

1. Install the [base cover](#).
2. Follow the procedure in [After working inside your computer](#).

Speakers



Removing the speakers

Prerequisites

1. Follow the procedure in [Before working inside your computer](#).
2. Remove the [base cover](#).

About this task

The following image indicates the location of the speakers and provides a visual representation of the removal procedure.



Steps

1. Disconnect the speaker cable from the Ethernet and audio board.
2. Remove the speaker cable from the routing guides along the bottom edge of the palm-rest and keyboard assembly.
3. Lift the speakers, along with its cable, off the palm-rest and keyboard assembly.



Installing the speakers

Prerequisites

If you are replacing a component, remove the existing component before performing the installation procedure.

About this task

The following image indicates the location of the speakers and provides a visual representation of the installation procedure.



Steps

1. Using the alignment posts and rubber grommets, place the speakers in the slots on the palm-rest and keyboard assembly
NOTE: If the rubber grommets are pushed out of the speakers when removing the speakers, push them back in place before replacing the speakers.
2. Connect the speaker cable to the Ethernet and audio board.
3. Route the speaker cable through the routing guides on the palm-rest and keyboard assembly.

Next steps

1. Install the [base cover](#).
2. Follow the procedure in [After working inside your computer](#).

Rear cover


Removing the rear cover

Prerequisites

1. Follow the procedure in [Before working inside your computer](#).
2. Remove the [base cover](#).

About this task

The following image indicates the location of the rear cover and provides a visual representation of the removal procedure.



Steps

1. Remove the two screws (M2x4) that secure the rear cover to the system board.
2. Remove the four screws (M2x5) that secure the rear cover to the palm-rest and keyboard assembly.
3. Push the rear cover away from the system board and lift it off the palm-rest and keyboard assembly.

Installing the rear cover

Prerequisites

If you are replacing a component, remove the existing component before performing the installation procedure.

About this task

The following image indicates the location of the rear cover and provides a visual representation of the installation procedure.



Steps





1. Slide the rear cover towards the system board till it snaps into place.
2. Align the screw holes on the rear cover with the screw holes on the palm-rest and keyboard assembly.
3. Replace the four screws (M2x5) that secure the rear cover to the system board.
4. Replace the two screws (M2x4) that secure the rear cover to the palm-rest and keyboard assembly.


Next steps

1. Install the [base cover](#).
2. Follow the procedure in [After working inside your computer](#).

Removing and installing Field Replaceable Units (FRUs)


The replaceable components in this chapter are Field Replaceable Units (FRUs).

-  **CAUTION:** The information in this removing and installing FRU's section is intended for authorized service technicians only.
-  **CAUTION:** To avoid any potential damage to the component or loss of data, ensure that an authorized service technician replaces the Field Replaceable Units (FRUs).
-  **CAUTION:** Dell Technologies recommends that this set of repairs, if needed, to be conducted by trained technical repair specialists.
-  **CAUTION:** As a reminder, your warranty does not cover damages that may occur during FRU repairs that are not authorized by Dell Technologies.

 **NOTE:** The images in this document may differ from your computer depending on the configuration you ordered.

Battery

Rechargeable Li-ion battery precautions

-  **CAUTION:**
 - Exercise caution when handling rechargeable Li-ion batteries.
 - Discharge the battery completely before removing it. Disconnect the AC power adapter from the computer and operate the computer solely on battery power—the battery is fully discharged when the computer no longer turns on when the power button is pressed.
 - Do not crush, drop, mutilate, or penetrate the battery with foreign objects.
 - Do not expose the battery to high temperatures, or disassemble battery packs and cells.
 - Do not apply pressure to the surface of the battery.
 - Do not bend the battery.
 - Do not use tools of any kind to pry on or against the battery.
 - To prevent accidental puncture or damage to the battery and other components, ensure that no screws are lost or misplaced during the servicing of this product.
 - If the battery gets stuck inside your computer as a result of swelling, do not try to release it as puncturing, bending, or crushing a rechargeable Li-ion battery can be dangerous. In such an instance, contact Dell technical support for assistance. See [Contact Support at Dell Support Site](#).
 - Always purchase genuine batteries from [Dell Site](#) or authorized Dell partners and resellers.
 - Swollen batteries should not be used and should be replaced and disposed properly. For guidelines on how to handle and replace swollen rechargeable Li-ion batteries, see [Handling swollen rechargeable Li-ion batteries](#).

Removing the battery


Prerequisites

1. Follow the procedure in [Before working inside your computer](#).

2. Remove the [base cover](#).

About this task

The following image indicates the location of the battery and provides a visual representation of the removal procedure.



Steps

1. Using the pull tab, disconnect the battery cable from the system board, if it is not previously disconnected.
2. Remove the four screws (M2x4) that secure the battery to the palm-rest and keyboard assembly.
3. Lift the battery at a 45 degree angle and remove it from the palm-rest and keyboard assembly.

Installing the battery

Prerequisites

If you are replacing a component, remove the existing component before performing the installation procedure.

About this task

The following image indicates the location of the battery and provides a visual representation of the installation procedure.





Steps

1. At a 45 degree angle, slide the battery into the slot on the palm-rest and keyboard assembly.
2. Align the screw holes on the battery with the screw holes on the palm-rest and keyboard assembly.
3. Replace the four screws (M2x4) that secure the battery to the palm-rest and keyboard assembly.
4. Connect the battery cable to the system board.
5. Adhere the tape to secure the battery cable to the system board.

Next steps

1. Install the [base cover](#).
2. Follow the procedure in [After working inside your computer](#).

Touchpad

Removing the touchpad

Prerequisites


1. Follow the procedure in [Before working inside your computer](#).
2. Remove the [base cover](#).
3. Remove the [battery](#).

About this task

The following image indicates the location of the touchpad and provides a visual representation of the removal procedure.



7x
M2x2



Steps

1. Open the latch and disconnect the touchpad cable from the system board.
2. Remove the three (M2x2) screws that secure the touchpad bracket to the palm-rest and keyboard assembly.
3. Lift the touchpad bracket off the touchpad.
4. Remove the four (M2x2) screws that secure the touchpad to the palm-rest and keyboard assembly.
5. Lift the touchpad off the palm-rest and keyboard assembly.

Installing the touchpad

Prerequisites



If you are replacing a component, remove the existing component before performing the installation procedure.

About this task

The following image indicates the location of the touchpad and provides a visual representation of the installation procedure.



7x
M2x2



Steps

1. Align and place the touchpad into the slot on the palm-rest and keyboard assembly.
2. Replace the four (M2x2) screws that secure the touchpad to the palm-rest and keyboard assembly.
3. Align and place the touchpad bracket into the slot on the palm-rest and keyboard assembly.
4. Replace the three (M2x2) screws that secure the touchpad bracket to the palm-rest and keyboard assembly.
5. Connect the touchpad cable to the system board and close the latch.

Next steps

1. Install the [battery](#).
2. Install the [base cover](#).
3. Follow the procedure in [After working inside your computer](#).

Display assembly

Removing the display assembly

Prerequisites




1. Follow the procedure in [Before working inside your computer](#).
2. Remove the [base cover](#).
3. Remove the [rear cover](#).

About this task

The following images indicate the location of the display assembly and provide a visual representation of the removal procedure.




8x
M2.5x4



Steps

1. Peel that tape that secures the display-cable latch to the system board.
2. Open the latch and disconnect the display cable from the system board.
3. Disconnect the dynamic-display switch (DDS) cable from the system board.

 **NOTE:** This step is applicable only for computers that are shipped with a 165 Hz or 240 Hz display.

4. Remove the antenna cables from the routing guides on the right fan.
5. Turn the computer over and place the computer on a clean and flat surface.
6. Remove the four screws (M2.5x4) that secure the left display-assembly hinge to the palm-rest and keyboard assembly.
7. Remove the antenna cables from the routing guides on the palm-rest and keyboard assembly, along the top side of the computer.
8. Remove the four screws (M2.5x4) that secure the right display-assembly hinge to the palm-rest and keyboard assembly.
9. Remove the display cable from the routing guides on the palm-rest and keyboard assembly, along the top side of the computer.
10. Gently lift the display assembly from the palm-rest and keyboard assembly.

Installing the display assembly

Prerequisites




If you are replacing a component, remove the existing component before performing the installation procedure.

About this task

The following image indicates the location of the display assembly and provides a visual representation of the installation procedure.




8x
M2.5x4



Steps

1. Place the display assembly on the palm-rest and keyboard assembly.
2. Align the screw holes on the display hinges with screw holes on the palm-rest and keyboard assembly.
3. Replace the four screws (M2.5x4) that secure the left display-assembly hinge to the palm-rest and keyboard assembly.
4. Route the antenna cables through the routing guides on the palm-rest and keyboard assembly, along the top side of the computer, and into the opening to the right of the power-adaptor port.
5. Replace the four screws (M2.5x4) that secure the right display-assembly hinge to the palm-rest and keyboard assembly.
6. Route the display cable through the routing guides on the palm-rest and keyboard assembly, along the top side of the computer, and into the opening to left of the USB 3.2 Gen 2 (Type-C) port.
7. Turn the computer over and place the computer on a clean and flat surface.
8. Route the antenna cables through the routing guides on the fan.
9. Connect the display cable to the connector on the system board and close the latch.
10. Adhere the tape that secures the display-cable connector latch to the system board.
11. Connect the dynamic-display switch (DDS) cable to the system board.

 **NOTE:** This step is applicable only for computers that are shipped with a 165 Hz or 240 Hz display.

Next steps

1. Install the [rear cover](#).
2. Install the [base cover](#).
3. Follow the procedure in [After working inside your computer](#).

Keyboard-controller board

Removing the keyboard-controller board

Prerequisites


1. Follow the procedure in [Before working inside your computer](#).
2. Remove the [base cover](#).
3. Remove the [battery](#).

About this task

 **NOTE:** The keyboard-controller board is only required for computers that are shipped with a 4-zone keyboard.



1x
M2x2



Steps

1. Open the latch and disconnect the keyboard-backlight cable from the keyboard-controller board.
2. Open the latch and disconnect the keyboard-controller board cable from the keyboard-controller board.
3. Remove the screw (M2x2) that secures the keyboard-controller board to the palm-rest and keyboard assembly.
4. Lift the keyboard-controller board off the palm-rest and keyboard assembly.

Installing the keyboard-controller board

Prerequisites


If you are replacing a component, remove the existing component before performing the installation process.

About this task

NOTE: The keyboard-controller board is only required for computers that are shipped with a 4-zone keyboard.



1x
M2x2



Steps

1. Using the alignment posts, place the keyboard-controller board into the slot on the palm-rest and keyboard assembly.
2. Replace the screw (M2x2) that secures the keyboard-controller board to the palm-rest and keyboard assembly.
3. Connect the keyboard-controller board cable to the keyboard-controller board and close the latch.
4. Connect the keyboard-backlight cable to the keyboard-controller board and close the latch.

Next steps

1. Install the [battery](#).
2. Install the [base cover](#).
3. Follow the procedure in [After working inside your computer](#).

Power-adapter port

Removing the power-adapter port

Prerequisites


1. Follow the procedure in [Before working inside your computer](#).
2. Remove the [base cover](#).
3. Remove the [rear cover](#).

About this task

The following image indicates the location of the power-adapter port and provides a visual representation of the removal procedure.



2x
M2x5



Steps

1. Remove the two screws (M2x5) that secure the power-adapter port bracket to the palm-rest and keyboard assembly.
2. Lift the power-adapter port-bracket off the power-adapter port.
3. Peel the power-adapter port cable off the system board.
4. Disconnect the power-adapter port-cable from the system board.
5. Lift the power-adapter port and its cable off the palm-rest and keyboard assembly.

Installing the power-adapter port

Prerequisites

If you are replacing a component, remove the existing component before performing the installation procedure.

About this task

The following image indicates the location of the power-adapter port and provides a visual representation of the installation procedure.



Steps

1. Place the power-adapter port into the slot and adhere the power-adapter port cable on the system board.
2. Connect the power-adapter port cable to the system board.
3. Place the power-adapter port bracket on the power-adapter port and align the screw holes on the power-adapter port bracket to the screw holes on the palm-rest and keyboard assembly.
4. Replace the two screws (M2x5) that secure the power-adapter port bracket to the palm-rest and keyboard assembly.

Next steps

1. Install the [rear cover](#).
2. Install the [base cover](#).
3. Follow the procedure in [After working inside your computer](#).

System board

Removing the system board (single-color keyboard)

NOTE: This procedure is applicable only for computers that are shipped with a single-color keyboard.

Prerequisites


1. Follow the procedure in [Before working inside your computer](#).
2. Remove the [base cover](#).
3. Remove the [battery](#).
4. Remove the [rear cover](#).
5. Remove the [solid-state drive](#).
6. Remove the [wireless card](#).
7. Remove the [memory module](#).

About this task

CAUTION: Before removing the system board, give sufficient time for the heat sink to cool down to avoid injury.

NOTE: Replacing the system board removes any changes that you have made to the BIOS using the BIOS Setup program. Make the appropriate changes again after you replace the system board.

The following image indicates the connectors on your system-board assembly.



- 1. Display cable
- 2. Dynamic-display switch (DDS) cable (applicable to computers with a 165 Hz or 240 Hz display)
- 3. Power-adaptor port cable
- 4. Right-fan cable
- 5. Touchpad cable
- 6. Keyboard cable
- 7. Keyboard-backlight cable
- 8. Left-fan cable

The following image indicates the location of the system board and provides a visual representation of the removal procedure.



Steps

1. Peel the tape that secures the display-cable connector latch to the system board.
2. Open the latch and disconnect the display cable from the system board.
3. Disconnect the dynamic-display switch (DDS) cable from the system board.

NOTE: This step is applicable only for computers that are shipped with a 165 Hz or 240 Hz display.

4. Remove the two (M2x5) screws that secure the Type-C bracket to the system board and lift the bracket off the system board.
5. Disconnect the power-adaptor port cable from the system board.
6. Peel the power-adaptor port cable off the system board.
7. Disconnect the right-fan cable from the system board.
8. Disconnect the speaker cable from the system board.
9. Open the latch and disconnect the touchpad cable from the system board.
10. Open the latch and disconnect the keyboard cable from the system board.
11. Open the latch and disconnect the keyboard-backlight cable from the system board.
12. Disconnect the left-fan cable from the system board.
13. Remove the five screws (M2x5) that secure the system board to the palm-rest and keyboard assembly.
14. Remove the screw (M2x3) that secures the USB board to the palm-rest and keyboard assembly.
15. Remove the screw (M2x3) that secures the Ethernet and audio board to the palm-rest and keyboard assembly.
16. Remove the screw (M2x4) that secures the left fan to the palm-rest and keyboard assembly.
17. Lift the system-board assembly off the palm-rest and keyboard assembly.

NOTE: Ensure that you lift the system board from the upper left and right sides of the heat sink.

18. Place the system-board assembly on a clean and flat surface.
19. Turn the system-board assembly over and remove the [Ethernet and audio board](#), [USB board](#), and [fan and heat-sink assembly](#).

Installing the system board (single-color keyboard)

NOTE: This procedure is applicable only for computers that are shipped with a single-color keyboard.


Prerequisites

If you are replacing a component, remove the existing component before performing the installation procedure.

NOTE: Replacing the system board removes any changes that you have made to the BIOS using the BIOS Setup program. Make the appropriate changes again after you replace the system board.


About this task

The following image indicates the connectors on your system board:




1. Display cable
2. Dynamic-display switch (DDS) cable
3. Power-adapter port cable
4. Right-fan cable
5. Touchpad cable
6. Keyboard cable
7. Keyboard-backlight cable
8. Left-fan cable

The following image indicates the location of the system board and provides a visual representation of the installation procedure.




Steps


1. Place the system board on a clean and flat surface.
2. Install the [Ethernet and audio board](#), [USB board](#), and [fan and heat-sink assembly](#).
3. Turn the system board over.
4. Using the alignment posts, place the system board on the palm-rest and keyboard assembly, ensuring that the heat sink is aligned against the top edge of the palm-rest and keyboard assembly.
5. Align the screw holes on the system board with the screw holes on the palm-rest and keyboard assembly.
6. Replace the five screws (M2x5) that secure the system board to the palm-rest and keyboard assembly.
7. Replace the screw (M2x3) that secures the USB board to the palm-rest and keyboard assembly.
8. Replace the screw (M2x3) that secures the Ethernet and audio board to the palm-rest and keyboard assembly.
9. Replace the screw (M2x4) that secures the left fan to the palm-rest and keyboard assembly.
10. Align the screw holes on the Type-C bracket with the screw holes on the system board.
11. Replace the two screws (M2x5) that secure the Type-C bracket to the system board.
12. Connect the Dynamic Display Switch (DDS) cable to the system board.

 **NOTE:** This step is applicable only for computers that are shipped with a 165 Hz or 240 Hz display.

13. Connect the display cable to the system board and close the latch.
14. Adhere the tape that secures the display-cable connector latch to the system board.
15. Connect the power-adaptor port cable to the system board.
16. Adhere the power-adaptor port cable on the system board.
17. With both hands, use your fingertips to push the right fan cable into its connector on the system board.

 **CAUTION:** Connecting the cable with the incorrect side facing upwards can damage the connector and the system board. Ensure that the black dot on the cable is facing upwards before connecting the cable.


18. Connect the speaker cable to the system board.
19. Connect the touchpad cable to the system board and close the latch.
20. Connect the keyboard cable to the system board and close the latch.
21. Connect the keyboard-backlight cable to the system board and close the latch.
22. With both hands, use your fingertips to push the left-fan cable into its connector on the system board.

 **CAUTION:** Connecting the cable with the incorrect side facing upwards can damage the connector and the system board. Ensure that the black dot on the cable is facing upwards before connecting the cable.

Next steps

1. Install the [memory module](#).
2. Install the [wireless card](#).
3. Install the [solid-state drive](#).
4. Install the [rear cover](#).
5. Install the [battery](#).
6. Install the [base cover](#).
7. Follow the procedure in [After working inside your computer](#).

Removing the system board (four-zone keyboard)

 **NOTE:** This procedure is applicable only for computers that are shipped with a four-zone keyboard.

Prerequisites

1. Follow the procedure in [Before working inside your computer](#).
2. Remove the [base cover](#).
3. Remove the [battery](#).
4. Remove the [rear cover](#).


5. Remove the [solid-state drive](#).
6. Remove the [wireless card](#).
7. Remove the [memory module](#).

About this task

CAUTION: Before removing the system board, give sufficient time for the heat sink to cool down to avoid injury.


NOTE: Replacing the system board removes any changes that you have made to the BIOS using the BIOS Setup program. Make the appropriate changes again after you replace the system board.

The following image indicates the connectors on your system-board assembly.



1. Display cable
2. Dynamic-display switch (DDS) cable
3. Power-adapter port cable
4. Right-fan cable
5. Touchpad cable
6. Keyboard cable
7. Keyboard-controller board cable
8. Left-fan cable

The following image indicates the location of the system board and provides a visual representation of the removal procedure.



Steps

1. Peel the tape that secures the display-cable connector latch to the system board.
2. Open the latch and disconnect the display cable from the system board.
3. Disconnect the dynamic-display switch (DDS) cable from the system board.

NOTE: This step is applicable only for computers that are shipped with a 165 Hz or 240 Hz display.

4. Remove the two (M2x5) screws that secure the Type-C bracket to the system board and lift the bracket off the system board.
5. Disconnect the power-adaptor port cable from the system board.
6. Peel the power-adaptor port cable off the system board.
7. Disconnect the right-fan cable from the system board.
8. Disconnect the speaker cable from the system board.
9. Open the latch and disconnect the touchpad cable from the system board.
10. Open the latch and disconnect the keyboard cable from the system board.
11. Open the latch and disconnect the keyboard-controller board cable from the system board.
12. Disconnect the left-fan cable from the system board.
13. Open the latch and disconnect the power-button cable from the USB board.
14. Remove the five screws (M2x5) that secure the system board to the palm-rest and keyboard assembly.
15. Remove the screw (M2x3) that secures the USB board to the palm-rest and keyboard assembly.
16. Remove the screw (M2x3) that secures the Ethernet and audio board to the palm-rest and keyboard assembly.
17. Remove the screw (M2x4) that secures the left fan to the palm-rest and keyboard assembly.
18. Lift the system-board assembly off the palm-rest and keyboard assembly.

NOTE: Ensure that you lift the system board from the upper left and right sides of the heat sink.

19. Place the system-board assembly on a clean and flat surface.
20. Turn the system-board assembly over and remove the [Ethernet and audio board](#), [USB board](#), and [fan and heat-sink assembly](#).

Installing the system board (four-zone keyboard)

NOTE: This procedure is applicable only for computers that are shipped with a four-zone keyboard.


Prerequisites

If you are replacing a component, remove the existing component before performing the installation procedure.

NOTE: Replacing the system board removes any changes that you have made to the BIOS using the BIOS Setup program. Make the appropriate changes again after you replace the system board.


About this task

The following image indicates the connectors on your system board.




1. Display cable
2. Dynamic-display switch (DDS) cable
3. Power-adapter port cable
4. Right-fan cable
5. Touchpad cable
6. Keyboard cable
7. Keyboard-controller board cable
8. Power-button cable
9. Left-fan cable

The following image indicates the location of the system board and provides a visual representation of the installation procedure.




Steps


1. Place the system board on a clean and flat surface.
2. Install the [Ethernet and audio board](#), [USB board](#), and [fan and heat-sink assembly](#).
3. Turn the system board over.
4. Using the alignment posts, place the system board on the palm-rest and keyboard assembly, ensuring that the heat sink is aligned against the top edge of the palm-rest and keyboard assembly.
5. Align the screw holes on the system board with the screw holes on the palm-rest and keyboard assembly.
6. Replace the five screws (M2x5) that secure the system board to the palm-rest and keyboard assembly.
7. Replace the screw (M2x3) that secures the USB board to the palm-rest and keyboard assembly.
8. Replace the screw (M2x3) that secures the Ethernet and audio board to the palm-rest and keyboard assembly.
9. Replace the screw (M2x4) that secures the left fan to the palm-rest and keyboard assembly.
10. Align the screw holes on the Type-C bracket with the screw holes on the system board.
11. Replace the two screws (M2x5) that secure the Type-C bracket to the system board.
12. Connect the Dynamic Display Switch (DDS) cable to the system board.

 **NOTE:** This step is applicable only for computers that are shipped with a 165 Hz or 240 Hz display.

13. Connect the display cable to the system board and close the latch.
14. Adhere the tape that secures the display-cable connector latch to the system board.
15. Connect the power-adaptor port cable to the system board.
16. Adhere the power-adaptor port cable on the system board.
17. With both hands, use your fingertips to push the right-fan cable into its connector on the system board.

 **CAUTION:** Connecting the cable with the incorrect side facing upwards can damage the connector and the system board. Ensure that the black dot on the cable is facing upwards before connecting the cable.

18. Connect the speaker cable to the system board.
19. Connect the touchpad cable to the system board and close the latch.
20. Connect the keyboard cable to the system board and close the latch.
21. Connect the keyboard-controller board cable to the system board and close the latch.
22. Connect the power-button cable to the USB board and close the latch.
23. With both hands, use your fingertips to push the left-fan cable into its connector on the system board.

 **CAUTION:** Connecting the cable with the incorrect side facing upwards can damage the connector and the system board. Ensure that the black dot on the cable is facing upwards before connecting the cable.

Next steps

1. Install the [memory module](#).
2. Install the [wireless card](#).
3. Install the [solid-state drive](#).
4. Install the [rear cover](#).
5. Install the [battery](#).
6. Install the [base cover](#).
7. Follow the procedure in [After working inside your computer](#).

USB board

Removing the USB board

Prerequisites


1. Follow the procedure in [Before working inside your computer](#).
2. Remove the [base cover](#).

3. Remove the [battery](#).
4. Remove the [rear cover](#).
5. Remove the [solid-state drive](#).
6. Remove the [wireless card](#).
7. Remove the [memory module](#).
8. Remove the [system board](#).

NOTE: The system board can be removed as an assembly with the fan and heat-sink assembly, Ethernet and audio board, and USB board attached.

About this task

The following image indicates the location of the USB board and provides a visual representation of the removal procedure.



Steps

1. Turn the system-board assembly over.
2. Remove the two screws (M2x4) that secure the USB board to the system-board assembly.
3. Disconnect and remove USB board from the system-board assembly.


Installing the USB board

Prerequisites

If you are replacing a component, remove the existing component before performing the installation procedure.

About this task

The following image indicates the location of the USB board and provides a visual representation of the installation procedure.



Steps

1. Slide the USB board into the M.2 card slot on the system board and align the screw holes on the USB board to the screw holes on the system board.
2. Replace the two screws (M2x4) that secure the USB board to the system board.
3. Turn the system-board assembly over.

Next steps

1. Install the [system board](#).
2. Install the [memory module](#).
3. Install the [wireless card](#).
4. Install the [solid-state drive](#).
5. Install the [rear cover](#).
6. Install the [battery](#).
7. Install the [base cover](#).
8. Follow the procedure in [After working inside your computer](#).

Ethernet and audio board

Removing the Ethernet and audio board

Prerequisites


About this task

The following image indicates the location of the Ethernet and audio board and provides a visual representation of the removal procedure.

1. Follow the procedure in [Before working inside your computer](#).
2. Remove the [base cover](#).
3. Remove the [battery](#).
4. Remove the [rear cover](#).

5. Remove the [solid-state drive](#).
6. Remove the [wireless card](#).
7. Remove the [memory module](#).
8. Remove the [system board](#).

NOTE: The system board can be removed as an assembly with the fan and heat-sink assembly, Ethernet and audio board, and USB board attached.



Steps

1. Turn the system-board assembly over.
2. Remove the two screws (M2x4) that secure the Ethernet and audio board to the system board.
3. Disconnect and remove the Ethernet and audio board from the system board.


Installing the Ethernet and audio board

Prerequisites

If you are replacing a component, remove the existing component before performing the installation procedure.

About this task

The following image indicates the location of the Ethernet and audio board and provides a visual representation of the installation procedure.



Steps

1. Slide the Ethernet and audio board into the M.2 card slot on the system board.
2. Align the screw holes on the Ethernet and audio board to the screw holes on the system board.
3. Replace the two screws (M2x4) that secure the Ethernet and audio board to the system board.
4. Turn the system-board assembly over.

Next steps

1. Install the [system board](#).
2. Install the [memory module](#).
3. Install the [wireless card](#).
4. Install the [solid-state drive](#).
5. Install the [rear cover](#).
6. Install the [battery](#).
7. Install the [base cover](#).
8. Follow the procedure in [After working inside your computer](#).

Fan and heat-sink assembly

Removing the fan and heat-sink assembly

Prerequisites

1. Follow the procedure in [Before working inside your computer](#).

CAUTION: For maximum cooling of the processor, do not touch the heat transfer areas on the heat sink. The oils in your skin can reduce the heat transfer capability of the thermal grease.

NOTE: The heat sink may become hot during normal operation. Allow sufficient time for the heat sink to cool before you touch it.


2. Remove the [base cover](#).

3. Remove the [battery](#).
4. Remove the [rear cover](#).
5. Remove the [solid-state drive](#).
6. Remove the [wireless card](#).
7. Remove the [memory module](#).
8. Remove the [system board](#).

i **NOTE:** The system board can be removed as an assembly with the fan and heat-sink assembly, Ethernet and audio board, and USB board attached.

About this task

The following image indicates the location of the fan and heat-sink assembly and provides a visual representation of the removal procedure.



Steps

1. Turn the system-board assembly over.
2. In sequential order (1>2>3>4>5>6>7), remove the seven screws that secure the fan and heat-sink assembly to the system-board assembly.
3. Lift the fan and heat-sink assembly off the system-board assembly.

Installing the fan and heat-sink assembly


Prerequisites

If you are replacing a component, remove the existing component before performing the installation procedure.

About this task

The following image indicates the location of the fan and heat-sink assembly and provides a visual representation of the installation procedure.

i **NOTE:** If either the system board or the heat sink is replaced, use the thermal pad that is provided in the kit to ensure that thermal conductivity is achieved.



Steps

1. Place the fan and heat-sink assembly on the system board and align the screw holes on the fan and heat-sink assembly with the screw holes on the system board.
2. In reverse sequential order (7>6>5>4>3>2>1), replace the seven screws that secure the fan and heat-sink assembly to the system board.
3. Turn the system-board assembly over.

Next steps

1. Install the [system board](#).
2. Install the [memory module](#).
3. Install the [wireless card](#).
4. Install the [solid-state drive](#).
5. Install the [rear cover](#).
6. Install the [battery](#).
7. Install the [base cover](#).
8. Follow the procedure in [After working inside your computer](#).

Power-button assembly

Removing the power button


Prerequisites

1. Follow the procedure in [Before working inside your computer](#).
2. Remove the [base cover](#).
3. Remove the [battery](#).
4. Remove the [rear cover](#).
5. Remove the [solid-state drive](#).
6. Remove the [wireless card](#).
7. Remove the [memory module](#).
8. Remove the [system board](#).

NOTE: The system board can be removed as an assembly with the fan and heat-sink assembly, Ethernet and audio board, and USB board attached.

About this task

The following images indicate the location of the power button and provide a visual representation of the removal procedure.



Steps

1. Remove the two screws (M2x2) that secure the power-button board assembly to the palm-rest and keyboard assembly.
2. Lift the power-button board assembly off the palm-rest and keyboard assembly.
3. Remove the screw (M2x2) that secures the power button to the palm-rest and keyboard assembly.
4. Lift the power button off the palm-rest and keyboard assembly.

Installing the power button

Prerequisites


If you are replacing a component, remove the existing component before performing the installation procedure.

About this task

The following image indicates the location of the power button and provides a visual representation of the installation procedure.



3x
M2x2



Steps

1. Place the power button on the slot on the palm-rest and keyboard assembly.
2. Replace the screw (M2x2) that secures the power button to the palm-rest and keyboard assembly.
3. Align the screw holes on the power-button board assembly with the screw holes on the palm-rest and keyboard assembly.
4. Replace the two screws (M2x2) that secure the power-button board assembly to the palm-rest and keyboard assembly.

Next steps

1. Install the [system board](#).
2. Install the [memory module](#).
3. Install the [wireless card](#).
4. Install the [solid-state drive](#).
5. Install the [rear cover](#).
6. Install the [battery](#).
7. Install the [base cover](#).
8. Follow the procedure in [After working inside your computer](#).

Palm-rest and keyboard assembly

Removing the palm-rest and keyboard assembly

Prerequisites

1. Follow the procedure in [Before working inside your computer](#).
2. Remove the [base cover](#).
3. Remove the [battery](#).
4. Remove the [rear cover](#).
5. Remove the [touchpad](#).
6. Remove the [display assembly](#).
7. Remove the [solid-state drive](#).
8. Remove the [wireless card](#).


9. Remove the [memory module](#).
10. Remove the [speakers](#).
11. Remove the [power adapter port](#).
12. Remove the [system board](#).

i **NOTE:** The system board can be removed as an assembly with the fan and heat-sink assembly, Ethernet and audio board, and USB board attached.

13. Remove the [keyboard-controller board](#), if applicable.
14. Remove the [power-button assembly](#).

About this task

After performing the steps in the pre-requisites, we are left with the palm-rest and keyboard assembly.



i **NOTE:** When replacing the palm-rest and keyboard assembly, the solid-state drive screw mount must be removed from the existing palm-rest and keyboard assembly and transferred to the replacement palm-rest and keyboard assembly.

Installing the palm-rest and keyboard assembly


Prerequisites

If you are replacing a component, remove the existing component before performing the installation procedure.

About this task

Place the palm-rest and keyboard assembly on a flat surface.

i **NOTE:** When replacing the palm-rest and keyboard assembly, the solid-state drive screw mount must be transferred from the old palm-rest and keyboard assembly to the replacement palm-rest and keyboard assembly.



Next steps

1. Install the [power-button assembly](#).
2. Install the [system board](#).

i **NOTE:** The system board can be installed as an assembly with the fan and heat-sink assembly, Ethernet and audio board, and USB board attached.

3. Install the [keyboard-controller board](#), if applicable.
4. Install the [power adapter port](#).
5. Install the [speakers](#).
6. Install the [memory module](#).
7. Install the [wireless card](#).
8. Install the [solid-state drive](#).
9. Install the [display assembly](#).
10. Install the [touchpad](#).
11. Install the [rear cover](#).
12. Install the [battery](#).
13. Install the [base cover](#).
14. Follow the procedure in [After working inside your computer](#).

Software

This chapter details the supported operating systems along with instructions on how to install the drivers.

Operating system

Your Dell G15 5530 supports the following operating systems:

- Windows 11 Professional, 64-bit
- Windows 11 Home, 64-bit
- Ubuntu 20.04 LTS, 64-bit

Drivers and downloads

When troubleshooting, downloading, or installing drivers, it is recommended that you read the Dell Knowledge Base article [Drivers and Downloads FAQs 000123347](#).

BIOS Setup

NOTE: Depending on the computer and the installed devices, the options that are listed in this section may or may not be displayed.

CAUTION: Certain changes can make your computer work incorrectly. Before you change the settings in BIOS Setup, it is recommended that you note down the original settings for future reference.

Use BIOS Setup for the following purposes:

- Get information about the hardware installed in your computer, such as the amount of RAM and the capacity of the storage device.
- Change the system configuration information.
- Set or change a user-selectable option, such as the user password, type of storage device installed, and enable or disable base devices.

Entering BIOS Setup program

About this task

Turn on (or restart) your computer and press F2 immediately.

Navigation keys

NOTE: For most of the BIOS Setup options, changes that you make are recorded but do not take effect until you restart the computer.

Table 25. Navigation keys

| Keys | Navigation |
|------------|--|
| Up arrow | Moves to the previous field. |
| Down arrow | Moves to the next field. |
| Enter | Selects a value in the selected field (if applicable) or follows the link in the field. |
| Spacebar | Expands or collapses a drop-down list, if applicable. |
| Tab | Moves to the next focus area. |
| Esc | Moves to the previous page until you view the main screen. Pressing Esc in the main screen displays a message that prompts you to save any unsaved changes and restart the computer. |

F12 One Time Boot menu

To enter the One Time Boot menu, turn on or restart your computer, and then press F12 immediately.

NOTE: If you are unable to enter the One Time Boot menu, repeat the above action.

The One Time Boot menu displays the devices that you can boot from and also display the options to start diagnostics. The boot menu options are:

- Removable Drive (if available)

- STXXXX Drive (if available)

NOTE: XXX denotes the SATA drive number.

- Optical Drive (if available)
- SATA Hard Drive (if available)
- Diagnostics

The One Time Boot menu screen also displays the option to access BIOS Setup.

System setup options

NOTE: Depending on this computer and its installed devices, the items that are listed in this section may or may not be displayed.

Table 26. System setup options—System information menu

| Overview | |
|-------------------------------|---|
| BIOS Version | Displays the BIOS version number. |
| Service Tag | Displays the Service Tag of the computer. |
| Asset Tag | Displays the Asset Tag of the computer. |
| Manufacture Date | Displays the manufacture date of the computer. |
| Ownership Date | Displays the ownership date of the computer. |
| Express Service Code | Displays the express service code of the computer. |
| Ownership Tag | Displays the ownership tag of the computer. |
| Signed Firmware Update | Displays whether the signed firmware update is enabled. |
| Battery | Displays the battery health information. |
| Primary | Displays the primary battery. |
| Battery Level | Displays the battery level. |
| Battery State | Displays the battery state. |
| Health | Displays the battery health. |
| AC Adapter | Displays whether an AC adapter is installed. |
| Processor | |
| Processor Type | Displays the processor type. |
| Maximum Clock Speed | Displays the maximum processor clock speed. |
| Minimum Clock Speed | Displays the minimum processor clock speed. |
| Current Clock Speed | Displays the current processor clock speed. |
| Core Count | Displays the number of cores on the processor. |
| Processor ID | Displays the processor identification code. |
| Processor L2 Cache | Displays the processor L2 Cache size. |
| Processor L3 Cache | Displays the processor L3 Cache size. |
| Microcode Version | Displays the microcode version. |
| Intel Hyper-Threading Capable | Displays whether the processor is Hyper-Threading (HT) capable. |
| 64-Bit Technology | Displays whether 64-bit technology is used. |
| Memory | |
| Memory Installed | Displays the total computer memory installed. |

Table 26. System setup options—System information menu (continued)

| Overview | |
|-----------------------|--|
| Memory Available | Displays the total computer memory available. |
| Memory Speed | Displays the memory speed. |
| Memory Channel Mode | Displays single or dual channel mode. |
| Memory Technology | Displays the technology that is used for the memory. |
| DIMM_Slot A | Displays the DIMM A memory size. |
| DIMM_Slot B | Displays the DIMM B memory size. |
| Devices | |
| Panel Type | Displays the Panel Type of the computer. |
| Video Controller | Displays the integrate graphics information of the computer. |
| Video Memory | Displays the video memory information of the computer. |
| Wi-Fi Device | Displays the wireless device information of the computer. |
| Native Resolution | Displays the native resolution of the computer. |
| Video BIOS Version | Displays the video BIOS version of the computer. |
| Bluetooth Device | Displays the Bluetooth device information of the computer. |
| Audio Controller | Displays the audio controller information of the computer. |
| LOM MAC Address | Displays the LOM MAC address of the computer. |
| dGPU Video Controller | Displays the discrete graphics information of the computer. |

Table 27. System setup options—Boot Configuration menu

| Boot Configuration | |
|------------------------------|---|
| Boot Sequence | |
| Boot Mode: UEFI only | Displays the boot mode of this computer. |
| Boot Sequence | Enables to set the boot order. |
| Secure Boot | |
| Enable Secure Boot | Enables secure boot using only validated boot software. Default: ON |
| Enable Microsoft UEFI CA | Enables Microsoft UEFI CA. Default: ON |
| Secure Boot Mode | Changes to the Secure Boot operation mode. Allows to switch between Deployed Mode and Audit Mode. Default: Deployed Mode |
| Expert Key Management | |
| Enable Custom Mode | Allows the PK, KEK, db, and dbx security key databases to be modified. Default: OFF |
| Custom Mode Key Management | Allows for selection of key database. |

Table 28. System setup options—Integrated Devices menu

| Integrated Devices |
|---------------------------|
| Date/Time |

Table 28. System setup options—Integrated Devices menu (continued)

| Integrated Devices | |
|--------------------------------------|---|
| Date | Sets the computer date in MM/DD/YYYY format. Changes to the date take effect immediately. |
| Time | Sets the computer time in HH/MM/SS 24-hour format. You can switch between 12-hour and 24-hour clock. Changes to the time take effect immediately. |
| Memory Mapped I/O above 4 Gig | Enables or disables the Memory Mapped I/O above 4 GB. Default: ON |
| Camera | |
| Enable Camera | Enables or disables the camera. By default, Enable Camera is selected. |
| Audio | |
| Enable Audio | Enables or disables all integrated audio controller. Default: ON |
| Enable Microphone | Enables or disables microphone. By default, Enable Microphone is selected. |
| Enable Internal Speaker | Enables or disables internal speaker. By default, Enable Internal Speaker is selected. |
| USB Configuration | |
| Enable External USB Ports | Enables or disables external USB ports. Default: ON |
| Enable USB Boot Support | Enables or disables USB Boot Support. Default: ON |

Table 29. System setup options—Storage menu

| Storage | |
|----------------------------|--|
| SATA/NVMe Operation | |
| SATA/NVMe Operation | Configures operating mode of the integrated storage device controller. Default: RAID On. Storage device is configured to support RAID functions. When enabled, all NVMe and SATA devices will be mapped under VMD controller. Windows RST (Intel Rapid Restore Technology) driver, or Linux kernel VMD driver must be loaded in order to boot the OS. |
| Storage Interface | |
| Port Enablement | Enables or disables the onboard drives. Default: ON |
| SMART Reporting | |
| Enable SMART Reporting | Enables or disables Self-Monitoring, Analysis, and Reporting Technology (SMART). Default: ON |
| Drive Information | Displays the information of various onboard drives. |

Table 30. System setup options—Display menu

| Display | |
|--|---|
| Display Brightness | |
| Brightness on battery power | Sets the screen brightness when the computer is running on battery power. |
| Brightness on AC power | Sets the screen brightness when the computer is running on AC power. |
| Full Screen Logo | |
| | Enables or disables full screen logo. |
| | By default, this option is disabled. |
| Hybrid Graphics/Advanced Optimus | |
| Enable Hybrid Graphics/Advanced Optimus (when available) | Enables or disables Hybrid Graphics/Advanced Optimus. |
| | Default: ON. |

Table 31. System setup options—Connection menu

| Connection | |
|---|--|
| Network Controller Configuration | |
| Integrated NIC | Enable or disable the on-board LAN controller. |
| | By default, the Enabled with PXE option is enabled. |
| Wireless Device Enable | |
| WLAN | Enable or disable the internal WLAN device. |
| | By default, this option is selected. |
| Bluetooth | Enable or disable the internal Bluetooth device |
| | By default, this option is selected. |
| Enable UEFI Network Stack | |
| | Enable or disable UEFI Network Stack and controls the on-board LAN Controller. |
| | By default, the Enabled option is selected. |
| HTTPs Boot Feature | |
| HTTPs Boot | Enable or disable the HTTPs Boot feature. |
| | Default: ON. |
| HTTPs Boot Modes | With Auto Mode, the HTTPs Boot extracts Boot URL from the DHCP. With Manual Mode, the HTTPs Boot reads Boot URL from the user-provided data. |
| | By default, the Auto Mode option is enabled. |
| Upload | Enables you to upload the CA certificate. |
| Delete | Enables you to delete the CA certificate. |

Table 32. System setup options—Power menu

| Power | |
|--|---|
| Battery Configuration | |
| | Enables the computer to run on battery during peak power usage hours. Use the Custom Charge Start and Custom Charge Stop options to prevent AC power usage between certain times of each day. |
| | By default, the Adaptive option is enabled. |
| Advanced Configuration | |
| Enable Advanced Battery Charge Configuration | Enables or disables the advanced battery charge configuration. |
| | Default: OFF |

Table 32. System setup options—Power menu (continued)

| Power | |
|-------------------------------------|--|
| | If enabled, use the Beginning of Day and Work Period sections to configure the daily times and work periods. |
| Thermal Management | Enables to cool the fan and processor heat management to adjust the system performance, noise, and temperature. By default, the Optimized option is selected. |
| Block Sleep | Enables to block entering Sleep (S3) mode in the operating system. Default: OFF |
| Lid Switch | |
| Enable Lid Switch | Enables or disables the Lid Switch Default: ON |
| Power On Lid Open | When enabled, allows the system to power up from the off state whenever the lid is opened. Default: ON |
| Intel Speed Shift Technology | Enable or disable the Intel Speed Shift Technology support. Default: ON |

Table 33. System setup options—Security menu



| Security | |
|--|---|
| Intel Platform Trust Technology | |
| Intel Platform Trust Technology On | Enables or disables Intel Platform Trust Technology visibility to operating system. Default: ON |
| PPI Bypass for Clear Commands | Controls the TPM Physical Presence Interface (PPI). By default, this option is disabled. |
| Clear | Enables to clear the PTT owner information and returns the PTT to the default state. By default, this option is disabled. |
| SMM Security Mitigation | Enables or disables additional UEFI SMM Security Mitigation protections. Default: ON |
| Data Wipe on Next Boot | |
| Start Data Wipe | Enables or disables the data wipe on next boot. Default: OFF |
| Absolute | Enables, disables, or permanently disables the BIOS module interface of the optional Absolute Persistence Module service from Absolute Software. By default, the Enable Absolute option is selected. |
| |  CAUTION: The 'Permanently Disable Absolute' option can only be selected once. When 'Permanently Disable Absolute' is selected, Absolute Persistence cannot be re-enabled. No further changes to the Enable/Disable states are allowed. |
| |  NOTE: The Enable/Disable options are unavailable while Computrace is in the activated state. |

Table 33. System setup options—Security menu (continued)

| Security | |
|--------------------------------|--|
| UEFI Boot Path Security | Controls whether the system prompts the user to enter the admin password (if set) when booting to a UEFI boot path device from the F12 boot menu. By default, the Always Except Internal HDD option is selected. |

Table 34. System setup options—Passwords menu

| Passwords | |
|------------------------------------|---|
| Admin Password | Set, change, or delete the administrator password. |
| System Password | Set, change, or delete the system password. |
| M.2 PCIe SSD-1 | Set, change, or delete the NVMe SSD-1 password. |
| Password Configuration | |
| Upper Case Letter | Reinforces password to have at least one upper case letter. By default, the option is disabled. |
| Lower Case Letter | Reinforces password to have at least one lower case letter. By default, the option is disabled. |
| Digit | Reinforces password to have at least one digit number. By default, the option is disabled. |
| Special Character | Reinforces password to have at least one special character. By default, the option is disabled. |
| Minimum Characters | Set the minimum characters allowed for password. |
| Password Bypass | When enabled, this always prompts for system and internal hard drive passwords when powered on from the Off state. By default, the Disabled option is selected. |
| Password Changes | |
| Allow Non-Admin Password Changes | Enables or disables to change system and hard drive password without the need for admin password. Default: ON |
| Admin Setup Lockout | |
| Enable Admin Setup Lockout | Enables administrators control over how their users can or cannot access BIOS Setup. Default: OFF |
| Master Password Lockout | |
| Enable Master Password Lockout | When enabled, this disables the master password support. Default: OFF |
| Allow Non-Admin PSID Revert | |
| Enable Allow Non-Admin PSID Revert | Controls access to the Physical Security ID (PSID) revert of NVMe hard-drives from the Dell Security Manager prompt. Default: OFF |

Table 35. System setup options—Update, Recovery menu

| Update, Recovery | |
|--------------------------------------|--|
| UEFI Capsule Firmware Updates | |

Table 35. System setup options—Update, Recovery menu (continued)

| Update, Recovery | |
|--|--|
| Enable UEFI Capsule Firmware Updates | <p>Enable or disable BIOS updates through UEFI capsule update packages.</p> <p>i NOTE: Disabling this option blocks BIOS updates from services such as Microsoft Windows Update and Linux Vendor Firmware Service (LVFS).</p> <p>Default: ON</p> |
| BIOS Recovery from Hard Drive | <p>Enables to recover from certain corrupted BIOS conditions from a recovery file on the user primary hard drive or an external USB key.</p> <p>Default: ON</p> <p>i NOTE: BIOS Recovery from Hard Drive is not available for self-encrypting drives (SED).</p> |
| BIOS Downgrade | |
| Allow BIOS Downgrade | <p>Controls the flashing of the system firmware to previous revisions.</p> <p>Default: ON</p> |
| SupportAssist OS Recovery | <p>Enables or disables the boot flow for SupportAssist OS Recovery tool in the event of certain system errors.</p> <p>Default: ON</p> |
| BIOSConnect | <p>Enables or disables cloud Service operating system recovery if the main operating system fails to boot with the number of failures equal to or greater than the value specified by the Auto operating system Recovery Threshold setup option and local Service operating system does not boot or is not installed.</p> <p>Default: ON</p> |
| Dell Auto operating system Recovery Threshold | <p>Controls the automatic boot flow for SupportAssist System Resolution Console and for Dell operating system Recovery Tool.</p> <p>By default, the threshold value is set to 2.</p> |

Table 36. System setup options—System Management menu

| System Management | |
|----------------------------|--|
| Service Tag | Displays the Service Tag of the system. |
| Asset Tag | Enables to create a system Asset Tag. |
| AC Behavior | |
| Wake on AC | <p>Enables or disables the wake on AC option.</p> <p>Default: OFF</p> |
| Auto On Time | <p>Enables to set the system to turn on automatically every day or on a preselected date and time. This option can be configured only if the Auto On Time is set to Everyday, Weekdays, or Selected Days.</p> <p>By default, the Disabled option is selected.</p> |
| First Power On Date | |
| Set Ownership Date | <p>Enables to set the ownership date.</p> <p>Default: OFF</p> |
| Diagnostics | |
| OS Agent Requests | <p>Enables or disables scheduling of onboard diagnostics on the subsequent boot.</p> <p>Default: ON</p> |

Table 36. System setup options—System Management menu (continued)

| System Management | |
|--|--|
| Power-on-Self-Test Automatic Recovery | Enables or disables automatic recovery if the computer is unresponsive after the BIOS Power-on-Self Test. Default: ON |

Table 37. System setup options—Keyboard menu

| Keyboard | |
|--|---|
| Fn Lock Options | Enables or disables the Fn lock options. Default: ON |
| Lock Mode | Enables or disables the Function keys to have secondary functions. By default, the Lock Mode Secondary option is enabled. With this option, the F1-F12 keys scan the code for their secondary functions. |
| Keyboard Illumination | Configures the keyboard illumination settings. By default, the Bright option is enabled. |
| Keyboard Backlight Timeout on AC | Sets the timeout value for the keyboard backlight when an AC adapter is connected to the system. By default, the 1 minute option is enabled. |
| Keyboard Backlight Timeout on Battery | Sets the timeout value for the keyboard backlight when the computer is running only on battery power. By default, the 1 minute option is enabled. |

Table 38. System setup options—Pre-boot Behavior menu

| Pre-boot Behavior | |
|------------------------------|---|
| Adapter Warnings | Enable Adapter Warnings Enables or disables the warning messages during boot when the adapters with less power capacity are detected. Default: ON |
| Warning and Errors | Sets the action to be taken when a warning or error is encountered. By default, the Prompt on Warnings and Errors option is enabled. |
| USB-C Warnings | Enables or disables dock warning messages. Default: ON |
| Fastboot | Allows you to configure the speed of the UEFI boot process. By default, the Thorough option is enabled. |
| Extend BIOS POST Time | Set the BIOS POST load time. By default, the 0 seconds option is enabled. |

Table 39. System setup options—Virtualization menu

| Virtualization | |
|--|---|
| Intel Virtualization Technology | Enable Intel Virtualization Technology (VT) When enabled, the system can run a Virtual Machine Monitor (VMM). Default: ON |
| VT for Direct I/O | |

Table 39. System setup options—Virtualization menu (continued)

| Virtualization | |
|--------------------------------|--|
| Enable Intel VT for Direct I/O | When enabled, the system can perform Virtualization Technology for Direct I/O (VT-d). Default: ON |
| DMA Protection | |
| Enable Pre-Boot DMA Support | This setting controls Pre-boot DMA protection for both internal and external ports. Default: ON |
| Enable OS Kernel DMA Support | This setting controls Kernel DMA protection for both internal and external ports. Default: ON |

Table 40. System setup options—Performance menu

| Performance | |
|---|--|
| Multi Core Support | |
| All Cores | Enables to select all cores to be available to the operating system. By default, this option is disabled. |
| Active Core Selection | Enables to set the number of CPU cores available to the operating system. By default, this option is disabled. |
| Multiple Atom Cores | Enables to change the number of Atom cores available to the operating system. By default, the All Cores option is enabled. |
| Intel SpeedStep | |
| Enable Intel SpeedStep Technology | Enables the system to dynamically adjust processor voltage and core frequency, decreasing average power consumption and heat production. Default: ON |
| C-States Control | |
| Enable C-State Control | Enables the ability of the CPU to enter and exit low power state. When disabled, it disabled all C-states. When enabled, it enabled all C-states that the chipset or platform allows. Default: ON |
| Enable Adaptive C-States for Discrete Graphics | Enables the ability of the CPU to dynamically detect high usage of a discrete graphic and adjust system parameters for higher performance. Default: ON |
| Intel Turbo Boost Technology | |
| Enable Intel Turbo Boost Technology | Enables or disables the Intel TurboBoost mode of the processor. Default: ON |
| Intel Turbo Boost Maximum Technology 3.0 | |
| Enable Intel Turbo Boost Maximum Technology 3.0 | Enables or disables the Intel TurboBoost maximum mode of the processor. Default: ON |
| Intel Hyper-Threading Technology | |
| Enable Intel Hyper-Threading Technology | Enables or disables Hyper-Threading in the processor. |

Table 40. System setup options—Performance menu (continued)

| Performance | |
|------------------------------|--|
| | Default: ON |
| OverClocking feature | Enables or disables global OverClocking functions. Default: OFF When enabled, OverClocking settings are available for selection. |
| TCC Activation Offset | Configures the CPU's TCC offset. |


Table 41. System setup options—System Logs menu

| System Logs | |
|--------------------------|---|
| BIOS Event Log | |
| Clear Bios Event Log | Displays BIOS events. By default, the Keep Log option is enabled. |
| Thermal Event Log | |
| Clear Thermal Event Log | Displays Thermal events. By default, the Keep Log option is enabled. |
| Power Event Log | |
| Clear Power Event Log | Displays power events. By default, the Keep Log option is enabled. |

Updating the BIOS

Updating the BIOS in Windows


Steps

1. Go to [Dell Support Site](#).
2. Go to **Identify your product or search support**. In the box, enter the product identifier, model, service request or describe what you are looking for, and then click **Search**.
 **NOTE:** If you do not have the Service Tag, use the SupportAssist to automatically identify your computer. You can also use the product ID or manually browse for your computer model.
3. Click **Drivers & Downloads**. Expand **Find drivers**.
4. Select the operating system installed on your computer.
5. In the **Category** drop-down list, select **BIOS**.
6. Select the latest version of BIOS, and click **Download** to download the BIOS file for your computer.
7. After the download is complete, browse the folder where you saved the BIOS update file.
8. Double-click the BIOS update file icon and follow the on-screen instructions.
For more information about how to update the system BIOS, search in the Knowledge Base Resource at [Dell Support Site](#).

Updating the BIOS using the USB drive in Windows

Steps

1. Go to [Dell Support Site](#).
2. Go to **Identify your product or search support**. In the box, enter the product identifier, model, service request or describe what you are looking for, and then click **Search**.

 **NOTE:** If you do not have the Service Tag, use the SupportAssist to automatically identify your computer. You can also use the product ID or manually browse for your computer model.

3. Click **Drivers & Downloads**. Expand **Find drivers**.
4. Select the operating system installed on your computer.
5. In the **Category** drop-down list, select **BIOS**.
6. Select the latest version of BIOS, and click **Download** to download the BIOS file for your computer.
7. Create a bootable USB drive. For more information, search the Knowledge Base Resource at [Dell Support Site](#).
8. Copy the BIOS Setup program file to the bootable USB drive.
9. Connect the bootable USB drive to the computer that needs the BIOS update.
10. Restart the computer and press **F12**.
11. Select the USB drive from the **One Time Boot Menu**.
12. Type the BIOS Setup program filename and press **Enter**.
The **BIOS Update Utility** appears.
13. Follow the on-screen instructions to complete the BIOS update.

Updating the BIOS in Linux and Ubuntu

To update the system BIOS on a computer that is installed with Linux or Ubuntu, see the knowledge base article [000131486](#) at [Dell Support Site](#).

Updating the BIOS from the One-Time boot menu

You can run the BIOS flash update file from Windows using a bootable USB drive or you can also update the BIOS from the One-Time boot menu on the computer. To update your computers BIOS, copy the BIOS XXXX.exe file onto a USB drive formatted with the FAT32 file system. Then, restart your computer and boot from the USB drive using the One-Time Boot Menu.

About this task

BIOS Update

To confirm if the BIOS Flash Update is listed as a boot option you can boot your computer to the **One Time Boot Menu**. If the option is listed, then the BIOS can be updated using this method.

To update your BIOS from the One-Time boot menu, you need the following:

- USB drive formatted to the FAT32 file system (the drive does not have to be bootable)
- BIOS executable file that you downloaded from the Dell Support website and copied to the root of the USB drive
- AC power adapter must be connected to the computer
- A functional computer battery to flash the BIOS

Perform the following steps to update the BIOS from the One-Time boot menu:

 **CAUTION: Do not turn off the computer during the BIOS flash update process. The computer may not boot if you turn off your computer.**

Steps

1. Turn off the computer, insert the USB drive that contains the BIOS flash update file.
2. Turn on the computer and press **F12** to access the **One Time Boot Menu**. Select **BIOS Update** using the mouse or arrow keys then press Enter.
The flash BIOS menu is displayed.
3. Click **Flash from file**.
4. Select the external USB device.
5. Select the file and double-click the flash target file, and then click **Submit**.
6. Click **Update BIOS**. The computer restarts to flash the BIOS.
7. The computer will restart after the BIOS flash update is completed.

System and setup password

CAUTION: The password features provide a basic level of security for the data on your computer.

CAUTION: Ensure that your computer is locked when it is not in use. Anyone can access the data that is stored on your computer, when left unattended.

Table 42. System and setup password

| Password type | Description |
|-----------------|---|
| System password | Password that you must enter to boot to your operating system. |
| Setup password | Password that you must enter to access and change the BIOS settings of your computer. |

You can create a system password and a setup password to secure your computer.

NOTE: The System and setup password feature is disabled by default.

Assigning a System Setup password

Prerequisites

You can assign a new System or Admin Password only when the status is set to **Not Set**. To enter BIOS System Setup, press F2 immediately after a power-on or reboot.

Steps

1. In the **System BIOS** or **System Setup** screen, select **Security** and press Enter.
The **Security** screen is displayed.
2. Select **System/Admin Password** and create a password in the **Enter the new password** field.
Use the following guidelines to create the system password:
 - A password can have up to 32 characters.
 - A password can at least have one special character: "(! " # \$ % & ' * + , - . / : ; < = > ? @ [\] ^ _ ` { | })"
 - A password can have numbers 0 to 9.
 - A password can have an upper case letters from A to Z.
 - A password can have a lower case letters from a to z.
3. Type the system password that you entered earlier in the **Confirm new password** field and click **OK**.
4. Press Y to save the changes.
The computer restarts.

Deleting or changing an existing system password or setup password


Prerequisites

Ensure that the **Password Status** is Unlocked in the System Setup before attempting to delete or change the existing system password and/or setup password. You cannot delete or change an existing system password or setup password if the **Password Status** is Locked. To enter the System Setup, press F2 immediately after a power-on or reboot.

Steps

1. In the **System BIOS** or **System Setup** screen, select **System Security** and press Enter.
The **System Security** screen is displayed.
2. In the **System Security** screen, verify that the **Password Status** is Unlocked.
3. Select **System Password**. Update or delete the existing system password, and press Enter or Tab.

4. Select **Setup Password**. Update or delete the existing setup password, and press Enter or Tab.

 **NOTE:** If you change the system password and/or setup password, reenter the new password when prompted. If you delete the system password and/or setup password, confirm the deletion when prompted.

5. Press Esc. A message prompts you to save the changes.
6. Press Y to save the changes and exit from **System Setup**.
The computer restarts.

Clearing CMOS settings

About this task

 **CAUTION:** Clearing CMOS settings will reset the BIOS settings on your computer.


Steps

1. Remove the [base cover](#).
2. Disconnect the battery cable from the system board.
3. Wait for one minute.
4. Connect the battery cable to the system board.
5. Replace the [base cover](#).

Clearing system and setup passwords

About this task

To clear the system or setup passwords, contact Dell technical support as described at [Contact Support](#).

 **NOTE:** For information about how to reset Windows or application passwords, see the documentation accompanying Windows or your application.

Troubleshooting

Handling swollen rechargeable Li-ion batteries

Like most laptops, Dell laptops use Lithium-ion batteries. One type of Lithium-ion battery is the rechargeable Li-ion battery. Rechargeable Li-ion batteries have increased in popularity in recent years and have become a standard in the electronics industry due to customer preferences for a slim form factor (especially with newer ultra-thin laptops) and long battery life. Inherent to rechargeable Li-ion battery technology is the potential for swelling of the battery cells.

A swollen battery may impact the performance of the laptop. To prevent possible further damage to the device enclosure or internal components leading to malfunction, discontinue the use of the laptop and discharge it by disconnecting the AC adapter and letting the battery drain.

Swollen batteries should not be used and must be replaced and disposed of properly. We recommend contacting Dell Support for options to replace a swollen battery under the terms of the applicable warranty or service contract, including options for replacement by a Dell authorized service technician.

The guidelines for handling and replacing rechargeable Li-ion batteries are as follows:

- Exercise caution when handling rechargeable Li-ion batteries.
- Discharge the battery before removing it from the laptop. To discharge the battery, unplug the AC adapter from the computer and operate the computer only on battery power. The battery is fully discharged when the computer no longer turns on when the power button is pressed.
- Do not crush, drop, mutilate, or penetrate the battery with foreign objects.
- Do not expose the battery to high temperatures, or disassemble battery packs and cells.
- Do not apply pressure to the surface of the battery.
- Do not bend the battery.
- Do not use tools of any type to pry on or against the battery.
- If a battery gets stuck in a device as a result of swelling, do not try to free it as puncturing, bending, or crushing a battery can be dangerous.
- Do not attempt to reassemble a damaged or swollen battery into a laptop.
- Swollen batteries that are covered under warranty should be returned to Dell in an approved shipping container (provided by Dell)—this is to comply with transportation regulations. Swollen batteries that are not covered under warranty should be disposed of at an approved recycling center. Contact Dell Support at [Dell Support Site](#) for assistance and further instructions.
- Using a non-Dell or incompatible battery may increase the risk of fire or explosion. Replace the battery only with a compatible battery purchased from Dell that is designed to work with your Dell computer. Do not use a battery from other computers with your computer. Always purchase genuine batteries from [Dell Site](#) or otherwise directly from Dell.

Rechargeable Li-ion batteries can swell for various reasons such as age, number of charge cycles, or exposure to high heat. For more information about how to improve the performance and lifespan of the laptop battery and to minimize the possibility of occurrence of the issue, search Dell laptop battery in the Knowledge Base Resource at [Dell Support Site](#).

Locating the Service Tag or Express Service Code of your Dell computer

Your Dell computer is uniquely identified with a Service Tag or Express Service Code. To view relevant support resources for your Dell computer, we recommend entering the Service Tag or Express Service Code at [Dell Support Site](#).


For more information about how to find the Service Tag for your computer, see [Instructions on how to find your Service Tag or Serial Number](#).

Dell SupportAssist Pre-boot System Performance Check diagnostics

About this task

SupportAssist diagnostics (also known as system diagnostics) performs a complete check of your hardware. The Dell SupportAssist Pre-boot System Performance Check diagnostics is embedded within the BIOS and launched by the BIOS internally. The embedded system diagnostics provides options for particular devices or device groups allowing you to:

- Run tests automatically or in an interactive mode.
- Repeat the tests.
- Display or save test results.
- Run thorough tests to add more options and obtain details about any failed devices.
- View status messages that inform you when the tests are completed successfully.
- View error messages that inform you of problems encountered during testing.

 **NOTE:** Some tests for specific devices require user interaction. Always ensure that you are present at the computer when the diagnostic tests are performed.

For more information, see the knowledge base article [000181163](#).

Running the SupportAssist Pre-Boot System Performance Check

Steps

1. Turn on your computer.
2. As the computer boots, press the F12 key.
3. On the boot menu screen, select **Diagnostics**.
The diagnostic quick test begins.


 **NOTE:** For more information about running the SupportAssist Pre-Boot System Performance Check on a specific device, see [Dell Support Site](#),

4. If there are any issues, error codes are displayed.
Note the error code and validation number and contact Dell.


Built-in self-test (BIST)

(Motherboard Built-In Self-Test) M-BIST

M-BIST is the system board built-in self-test diagnostics tool that improves the diagnostics accuracy of system board Embedded Controller (EC) failures.

 **NOTE:** M-BIST can be manually initiated before Power On Self-Test (POST).

How to run M-BIST

 **NOTE:** Before initiating M-BIST, ensure that the computer is in a power-off state.

1. Press and hold both the **M** key and the power button to initiate M-BIST.
2. The battery indicator LED may exhibit two states:
 - Off: No fault was detected.
 - Amber and White: Indicates a problem with the system board.
3. If there is a failure with the system board, the battery status LED flashes one of the following error codes for 30 seconds:


Table 43. LED error codes

| Blinking Pattern | | Possible Problem |
|------------------|-------|------------------------|
| Amber | White | |
| 2 | 1 | CPU Failure |
| 2 | 8 | LCD Power Rail Failure |
| 1 | 1 | TPM Detection Failure |
| 2 | 4 | Memory/RAM failure |

4. If there is no failure with the system board, the LCD cycles through the solid color screens (that are described in the LCD-BIST) for 30 seconds and then turn off.

Logical Built-in Self-test (L-BIST)

L-BIST is an enhancement to the single LED error code diagnostics and is automatically initiated during POST. L-BIST will check the LCD power rail. If there is no power being supplied to the LCD (that is if the L-BIST circuit fails), the battery status LED flashes either an error code [2,8] or an error code [2,7].

 **NOTE:** If L-BIST fails, LCD-BIST cannot function as no power will be supplied to the LCD.

How to invoke the L-BIST

1. Turn on your computer.
2. If the computer does not start up normally, look at the battery status LED:
 - If the battery status LED flashes an error code [2,7], the display cable may not be connected properly.
 - If the battery status LED flashes an error code [2,8], there is a failure on the LCD power rail of the system board, hence there is no power that is supplied to the LCD.
3. For cases, when a [2,7] error code is shown, check to see if the display cable is properly connected.
4. For cases when a [2,8] error code is shown, replace the system board.


LCD Built-in Self-Test (LCD-BIST)

Dell laptops have a built-in diagnostic tool that helps you determine if the screen abnormality you are experiencing is an inherent problem with the LCD (screen) of the Dell laptop or with the video card (GPU) and computer settings.

When you notice screen abnormalities like flickering, distortion, clarity issues, fuzzy or blurry image, horizontal or vertical lines, color fade, it is always a good practice to isolate the LCD (screen) by running the LCD-BIST.

How to invoke the LCD-BIST

1. Turn off your computer.
2. Disconnect any peripherals that are connected to the computer. Connect only the AC adapter (charger) to the computer.
3. Ensure that the LCD (screen) is clean (no dust particles on the surface of the screen).
4. Press and hold the **D** key and press the power button to enter LCD-BIST mode. Continue to hold the **D** key until the computer boots up.
5. The screen displays solid colors and changes colors on the entire screen to white, black, red, green, and blue twice.
6. Then it displays the colors white, black, and red.
7. Carefully inspect the screen for abnormalities (any lines, fuzzy color, or distortion on the screen).
8. At the end of the last solid color (red), the computer shuts down.

 **NOTE:** Dell SupportAssist Preboot diagnostics upon launch initiates an LCD-BIST first, expecting a user intervention to confirm functionality of the LCD.

System-diagnostic lights

Battery-status light

Indicates the power and battery-charge status.

Solid white — Power adapter is connected and the battery has more than 5 percent charge.

Amber — Computer is running on battery and the battery has less than 5 percent charge.

Off

- Power adapter is connected, and the battery is fully charged.
- Computer is running on battery, and the battery has more than 5 percent charge.
- Computer is in sleep state, hibernation, or turned off.

The battery-status light blinks amber along with beep codes indicating failures.

For example, the battery-status light blinks amber two times followed by a pause, and then blinks white three times followed by a pause. This 2,3 pattern continues until the computer is turned off indicating no memory or RAM is detected.

The following table shows different power and battery-status light patterns and associated problems.

Table 44. System diagnostic lights

| Blinking pattern | | Problem description |
|------------------|-------|--|
| Amber | White | |
| 1 | 1 | TPM detection failure |
| 1 | 2 | Unrecoverable SPI Flash Failure |
| 1 | 3 | Short in hinge cable tripped OCP1 |
| 1 | 4 | Short in hinge cable tripped OCP2 |
| 1 | 5 | EC unable to program i-Fuse |
| 1 | 6 | Generic catch-all for ungraceful EC code flow errors |
| 1 | 7 | Non-RPMC Flash on Boot Guard fused system |
| 2 | 1 | CPU failure |
| 2 | 2 | System board failure (included BIOS corruption or ROM error) |
| 2 | 3 | No memory/RAM detected |
| 2 | 4 | Memory/RAM failure |
| 2 | 5 | Invalid memory installed |
| 2 | 6 | System board/Chipset Error |
| 2 | 7 | LCD failure (SBIOS message) |
| 2 | 8 | LCD failure (EC detection of power rail failure) |
| 3 | 1 | CMOS battery failure |
| 3 | 2 | PCI or Video card/chip failure |
| 3 | 3 | BIOS recovery image not found |
| 3 | 4 | BIOS recovery image found but invalid |
| 3 | 5 | Power rail failure |
| 3 | 6 | Flash corruption detected by SBIOS. |

Table 44. System diagnostic lights (continued)

| Blinking pattern | | Problem description |
|------------------|-------|---|
| Amber | White | |
| 3 | 7 | Timeout waiting on ME to reply to HECI message. |

NOTE: Blinking 3-3-3 LEDs on Lock LED (Caps-Lock or Num-Lock), Power button LED (without Fingerprint reader), and Diagnostic LED indicates failure to provide input during LCD panel test on Dell SupportAssist Pre-boot System Performance. Check diagnostics.

Camera status light: Indicates whether the camera is in use.

- Solid white — Camera is in use.
- Off — Camera is not in use.

Caps Lock status light: Indicates whether Caps Lock is enabled or disabled.

- Solid white — Caps Lock enabled.
- Off — Caps Lock disabled.

Recovering the operating system

When your computer is unable to boot to the operating system even after repeated attempts, it automatically starts Dell SupportAssist OS Recovery.

Dell SupportAssist OS Recovery is a stand-alone tool that is preinstalled in Dell computers running the Windows operating system. It consists of tools to diagnose and troubleshoot issues that may occur before your computer boots to the operating system. It enables you to diagnose hardware issues, repair your computer, back up your files, and restore your computer to its factory state.

You can also download it from the Dell Support website to troubleshoot and fix your computer when it fails to boot into the primary operating system due to software or hardware failures.

For more information about the Dell SupportAssist OS Recovery, see *Dell SupportAssist OS Recovery User's Guide at Serviceability Tools at the Dell Support Site*. Click **SupportAssist** and then click **SupportAssist OS Recovery**.

Real-Time Clock (RTC Reset)

The Real-Time Clock (RTC) reset function enables you or the service technician to recover Dell computers from No POST/No Power/No Boot situations.

Start the RTC reset with the computer powered off and connected to AC power. Press and hold the power button for twenty five seconds . The computer RTC Reset occurs after you release the power button.

Backup media and recovery options


It is recommended to create a recovery drive to troubleshoot and fix problems that may occur with Windows. Dell provides multiple options for recovering the Windows operating system on your Dell computer. For more information, see [Dell Windows Backup Media and Recovery Options](#).

Network power cycle

About this task

If your computer is unable to access the Internet due to network connectivity issues, reset your network devices by performing the following steps:

Steps

1. Turn off the computer.
2. Turn off the modem.
 **NOTE:** Some Internet service providers (ISPs) provide a modem and router combo device.
3. Turn off the wireless router.
4. Wait for 30 seconds.
5. Turn on the wireless router.
6. Turn on the modem.
7. Turn on the computer.

Drain flea power (perform hard reset)

About this task

Flea power is the residual static electricity that remains in the computer even after it has been powered off and the battery is removed.

For your safety, and to protect the sensitive electronic components in your computer, you must drain residual flea power before removing or replacing any components in your computer.

Draining flea power, also known as performing a "hard reset," is also a common troubleshooting step if your computer does not turn on or boot into the operating system.

Perform the following steps to drain the flea power:

Steps

1. Turn off the computer.
2. Disconnect the power adapter from the computer.
3. Remove the base cover.
4. Remove the battery.



CAUTION: The battery is a Field Replaceable Unit (FRU) and the removal and installation procedures are intended for authorized service technicians only.

5. Press and hold the power button for 20 seconds to drain the flea power.
6. Install the battery.
7. Install the base cover.
8. Connect the power adapter to the computer.
9. Turn on the computer.





NOTE: For more information about performing a hard reset, go to [Dell Support Site](#). On the menu bar at the top of the Support page, select Support > Support Library. In the Search field on the Support Library page, type the keyword, topic, or model number, and then click or tap the search icon to view the related articles.

Getting help and contacting Dell

Self-help resources

You can get information and help on Dell products and services using these self-help resources:


Table 45. Self-help resources

| Self-help resources | Resource location |
|--|---|
| Information about Dell products and services | Dell Site |
| My Dell app |  |
| Tips |  |
| Contact Support | In Windows search, type <code>Contact Support</code> , and press Enter. |
| Online help for operating system | Windows Support Site Linux Support Site |
| Access top solutions, diagnostics, drivers and downloads, and learn more about your computer through videos, manuals, and documents. | Your Dell computer is uniquely identified using a Service Tag or Express Service Code. To view relevant support resources for your Dell computer, enter the Service Tag or Express Service Code at Dell Support Site . For more information about how to find the Service Tag for your computer, see Locate the Service Tag on your computer . |
| Dell knowledge base articles | <ol style="list-style-type: none"> 1. Go to Dell Support Site. 2. On the menu bar at the top of the Support page, select Support > Support Library. 3. In the Search field on the Support Library page, type the keyword, topic, or model number, and then click or tap the search icon to view the related articles. |

Contacting Dell

To contact Dell for sales, technical support, or customer service issues, see [Contact Support at Dell Support Site](#).

 **NOTE:** Availability of the services may vary depending on the country or region, and product.

 **NOTE:** If you do not have an active Internet connection, you can find contact information about your purchase invoice, packing slip, bill, or Dell product catalog.